


1. CONNECT AMP METER IN SERIES BY REMOVING THE WIRE NUT FROM THE RED MOTOR LEAD.




3. LOOSEN ADJ. 1 1/8" NUTS ON BOTH SIDES OF THE SLIDE ASSEMBLY ANGLE.

4. ONLY ADJUST 3 TO 4 TURNS (1/4") AT A TIME AND CHECK YOUR AMPS. AFTER EACH ADJUSTMENT. NOTE: YOUR AMPS. UP, OPENING, SHOULD BE AT LEAST 1/2 (.5) AMPS LOWER THAN YOUR AMPS. DOWN, CLOSING.

5. IF GATE OPENS SLOW, RAISE THE SLIDE ASSEMBLY.
IF GATE WILL NOT CLOSE, LOWER THE SLIDE ASSEMBLY.
IF GATE STALLS IN EITHER DIRECTION, YOU OVER-ADJUSTED.
BACK OFF YOUR LAST ADJUSTMENT AND CHECK AMPS.

6. IF GATE IS SLOW TO CLOSE FROM THE OPEN POSITION, INCREASE LENGTH OF T-BOLT.



UP: ______10°______55°_____85°

DOWN: ______10°_____55°_____85°

			DO NOT SCALE		1
Rev.:	Description:	Date:	Dm. By:	Ckd. By:	
С	Black motor wire was blue and added thread details	06/18/14	MKS	DMR	Ļ
В	Revised motor and slide assembly to current style	04/07/09	MKS	DMR	ľ
Α	General Revision , new Title Block	04/07/09	MKS	DMR	

NOTICE
THE INFORMATION CONTAINED
ON THIS DOCUMENT IS
CONFIDENTIAL ANY
DISSEMINATION, UNAPPROVED
DISCLOSURE OR COPYING OF
THIS INFORMATION IS
STRICTLY PROHIBITED
UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES
ANGLES & 19

X/X ± 1/32, ,XX ± .01, .XXX ± .005

ADJUSTMENT ROD-

T-BOLT

0 0 0 0 0 0 0 0 0 0 0 0

Dm. By: MKS
Ckd. By: DMR

04/03/07

AG

AutoGate
Gate Entry Systems

Bertlin Heights. Ohlo
FAX (419) 586-3514

GREASE

FITTINGS (6 TOTAL)

Dwg.: 107

Date:

Title: Balancing Slide Assembly