



VERTICAL PIVOT GATE OPERATOR

INSTALLATION AND OPERATION MANUAL



AG # _____


CURBS

HIGH SECURITY

CRASH

RAILROAD

CUSTOM






VERTICAL PIVOT GATE OPERATOR

INSTALLATION MANUAL

- THIS PRODUCT IS TO BE INSTALLED AND SERVICED BY AN EXPERIENCED TRAINED GATE SYSTEMS TECHNICIAN ONLY
- This model is used for vehicular gate traffic ONLY and not intended for pedestrian use.
- This model is intended for use in Class I, II, III and IV vehicular Vertical Pivot gate applications (See page 2 for usage class info)



FULL SIZE MANUAL AVAILABLE TO DOWNLOAD AND PRINT AT WWW.AUTOGATE.COM



MODEL VPG2490

TABLE OF CONTENTS

INTRODUCTION

SECTION 1—SAFETY

SAFETY SIGN AND SYMBOL REVIEW	4
USAGE CLASS.....	5
UL325 ENTRAPMENT PROTECTION REQUIREMENTS...	5
GENERAL SAFETY INSTALLATION.....	6
SAFETY INSTALLATION INFORMATION UL325.....	7
GATE CONSTRUCTION INFORMATION ASTM F2200.....	8

SECTION 2-OPERATOR INFORMATION

TERMS.....	9
OPERATOR COMPONENTS.....	10
SPECIFICATIONS.....	11

SECTION 3-SITE

TYPICAL LAYOUTS & CONDUITS.....	12
PAD LAYOUTS.....	13
LEFT & RIGHT STANDARD PAD LAYOUTS.....	14

SECTION 4-RECEIVING

RECEIVING & UNLOADING GATE AND OPERATOR.....	15
ATTACHING GATE TO OPERATOR.....	16
LIFTING AND POSITIONING ASSEMBLED OPERATOR....	17
MANUAL OPERATION.....	18
WINDBRACING.....	19
GATE GUARDS.....	20

SECTION 5-ELECTRICAL

ELECTRICAL.....	21
GROUNDING AND LIGHTENING PROTECTION.....	22
INSTALLING YOUR BATTERIES.....	22

SECTION 6-GENESIS BOARD

GENESIS BOARD	23
GENESIS BOARD MENUS.....	24-30
WIRING SCHEMATIC.....	31

SECTION 7 —ACCESSORY WIRING

NON-CONTACT ENTRAPMENT DEVICES.....	32
CONTACT ENTRAPMENT DEVICES.....	33-34
OPERATIONAL INPUTS.....	35-36
OPERATIONAL RELAYS.....	37
DUAL GATE.....	38
LPS-LIMIT POSITION SENSOR.....	38

SECTION 8—GENESIS TROUBLESHOOTING

GENESIS FAQ'S.....	39-40
TOUBLESOOTING THE GENESIS BOARD.....	41

SECTION 9—SERVICE & MAINTENANCE

RECOMMENDED MAINTENANCE.....	42
MAINTENANCE OPERATOR DETAILS.....	43
BELT CHANGING INSTRUCTIONS.....	44
SPRING CHANGING INSTRUCTIONS.....	45
BALANCING YOUR GATE.....	46

INTRODUCTION

AutoGate Vertical Pivot Gate Systems (VPGs) are offered in many styles and aesthetic uniqueness that surpass our competition. Each system is quoted, designed, assembled and fabricated uniquely to each site. Nothing is cookie cutter at Autogate except for our quality and commitment for delivering an exceptional product. In an industry of products that force the site or project to adjust to the limitation of a system, AutoGate seeks to adapt our systems to meet and exceed current, planned and future site conditions. VPGs are customizable for all site conditions:

- ♦ Varying road grades
- ♦ Curbs
- ♦ Space limitations
- ♦ Security requirements
- ♦ Weather conditions
- ♦ Aesthetic desires

These are true and consistent product differentiators.

Automatic Gate Operators can produce high levels of force, therefore, it is very important that all gate operator system installers and designers are fully aware of potential hazards that exist with an incorrectly installed or designed systems. The internal safety capabilities of a gate operator system are not enough to reduce the risk of injury. The operator is only one part of a properly installed system which when combined with all ASTM F2200 requirements and correctly installed approved entrapment devices will yield a completed UL 325, 7th edition/CSA 22.2 NO. 247-14 listed system that will not only provide convenience and security, but will be safer with a minimal risk of injury. This gate system should only be installed and serviced by a trained and preferably a Certified Gate Operator Installer. The following information contained in this manual along with the installation checklist provided will make you aware of potential areas that are of a safety concern. Disregarding any of the following may result in **SERIOUS INJURY OR DEATH!**

SECTION 1 — SAFETY

SAFETY SIGN AND SYMBOL REVIEW

When you see these Safety Symbols and Signal Words on the following pages, they will alert you to the possibility of Serious Injury or Death if you do not comply with the warnings. The hazard may come from something mechanical or from electric shock. Read the warnings carefully, they will alert you to the possibility of damage to your gate and/or the gate operator if you do not comply with the cautionary statements that accompany it. Read them carefully.

	WARNING
	ELECTRICAL
	CAUTION
	NOTE

IMPORTANT NOTE:

- **BEFORE** attempting to install, operate or maintain the operator, you must read and fully understand this manual and follow all safety instructions.
- **DO NOT** attempt repair or service of your gate operator unless you are an experienced Technician or a factory trained Service Technician.



WARNING: This product can expose you to chemicals including lead, which are known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

USAGE CLASS

CLASS I - RESIDENTIAL VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in garages or parking areas associated with a residence of one- to four single families.

CLASS II - COMMERCIAL/GENERAL ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units), hotel, garages, retail store, or other buildings accessible by or servicing the general public.

CLASS III - INDUSTRIAL/LIMITED ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory, loading dock area or other locations not accessible by or intended to service the general public.

CLASS IV - RESTRICTED ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.

UL 325 ENTRAPMENT PROTECTION REQUIREMENTS

VERTICAL PIVOT GATE OPERATOR

GATE OPERATOR ENTRAPMENT PROTECTION TYPES

TYPE A	Inherent (built into the operator) entrapment protection system
TYPE B1	Non-contact sensors such as photoelectric sensors/beams
TYPE B2	Contact sensors such as edge sensors

The same type of device shall not be used for both entrapment protection means. Use of a single device to cover both the opening and closing directions is in accordance with the requirement; however a single device is not required to cover both directions. This operator is provided with Type A. The installer is required to install additional entrapment protection devices in each entrapment zone.



WARNING

IMPORTANT SAFETY INSTRUCTIONS

WARNING—TO REDUCE THE RISK OF INJURY OR DEATH, READ AND FOLLOW ALL INSTRUCTIONS.

1. Never let children operate or play with gate controls. Keep the remote control away from children.
2. Always keep people and objects away from the gate. NO ONE SHOULD CROSS THE PATH OF THE MOVING GATE.
3. DO NOT OPEN the Gate Operator cabinet while gate is in motion
4. Test the gate operator monthly. The gate MUST reverse on contact with a rigid object or stop when an object activates the non-contact sensors. After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of injury or death.
5. Use the emergency release only when the gate is not moving.
6. KEEP GATES PROPERLY MAINTAINED. Read the user's manual. Have a qualified service person make repairs to gate hardware.
7. The entrance is for vehicles only. Pedestrians must use a separate entrance.
8. SAVE THESE INSTRUCTIONS.

GENERAL SAFETY INSTALLATION INFORMATION



WARNING!

INSTALL AND OPERATE THE GATE OPERATOR ONLY WHEN:

1. The operator is appropriate for the construction of the gate and the usage Class of the gate.
2. All areas of the moving vertical pivot gate panel from the bottom of the gate to the top of the gate or a minimum of 1.83 m (72 in) above grade, whichever is less, that pass by a fixed stationary object, and in the area of the adjacent fence that the gate covers during the travel of the gate, shall be designed, guarded or screened to prevent a 57 mm (2-1/4 in) diameter sphere from passing through such areas.
3. All exposed pinch points are eliminated or guarded
4. The installer has ensured “a)” through “h)” below are clearly understood and followed:
 - a) The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
 - b) The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
 - c) For gate operators utilizing Type D protection:
 - 1) The gate operator controls must be placed so that the user has full view of the gate area when the gate is moving,
 - 2) Automatic closing devices (such as a timer, loop sensor, or similar device) shall not be employed, and
 - 3) No other activation devices shall be connected.
 - d) Permanently mounted controls intended for user activation must be located at least 1.83 m (6 ft) away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls.

Exception: Emergency access controls only accessible by authorized personnel (e.g. fire, police, EMS) may be placed at any location in the line-of-sight of the gate.

- e) The Stop and/or Reset button must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
- f) A minimum of two (2) WARNING SIGNS shall be installed in the gate area. Each warning sign is to be visible by persons located on the side of the gate on which the placard is installed in the open or closed position.
- g) For gate operators utilizing a non-contact sensors:
 - 1) See instructions on the placement of non-contact sensors for each type (**A, B1, B2**) of application,
 - 2) Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle, trips the sensor while the gate is still moving, and
 - 3) One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.
- h) For a gate operator utilizing a contact sensors:
 - 1) One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as at the leading edge and trailing edge.
 - 2) One or more contact sensors shall be located at any pinch point of a vehicular vertical pivot gate.
 - 3) A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subjected to mechanical damage.

INSTALLATION INFORMATION PER UL 325

1. Vehicular gate systems provide convenience and security. Gate systems are comprised of many component parts. The gate operator is only one component. Each gate system is specifically designed for an individual application.
2. Gate operating system designers, installers and users must take into account the possible hazards associated with each individual application. Improperly designed, installed or maintained systems can create risks for the user as well as the bystander. Gate systems design and installation must reduce public exposure to potential hazards.
3. A gate operator can create high levels of force in its function as a component part of a gate system. Therefore, safety features must be incorporated into every design. Specific safety features include:
 - Contact Edge Sensors
 - Guards for Entrapment Areas
 - Photoelectric Sensors/Beams
 - Screen Mesh
 - Instructional and Precautionary Signage
4. Install the gate operator only when:
 - The operator is appropriate for the construction and the usage class of the gate.
 - All openings or leading edge of a Vertical Pivot gate operator that pass by any fixed stationary objects while traveling open or closing, shall be designed, guarded or screened to prevent a 2 ¼" (57mm) sphere from passing through or entering the protected area designed to prevent entrapment.
5. The operator system is intended for vehicular traffic only! Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the pedestrian access (gate) such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
6. The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment.
7. The gate must be properly installed and work freely in both directions when disengaged from the gate operator drive system.
8. Controls intended for user activation must be located at least 6 feet (1.8 m) away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.

Exception: Emergency access controls only accessible by authorized personnel (e.g. fire, police) may be placed at any location in the line-of-sight of the gate.
9. The Stop and/or Reset (if provided separately) must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
10. A minimum of two (2) WARNING SIGNS shall be installed, one on each side of the gate where easily visible.
11. For a gate operator utilizing a non-contact sensor:
 - Reference owner's manual regarding placement of non-contact sensor for each type of application. See Install Entrapment Protection section.
 - Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate is still moving.
 - One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.
12. For a gate operator utilizing a contact edge sensor:
 - One or more contact sensors shall be located where the risk of entrapment or obstruction exists.
 - A hard wired contact sensor shall be located and its wiring arranged so the communication between the sensor and the gate operator is not subject to mechanical damage.

NOTE

At least two (2) independent protection means are required in each direction of travel. The term "means" refers to devices such as Type "A" (Inherent Limit/Position Sensor) or "B1" (Non-Contact sensors/beams) and "B2" (Contact Edge Sensors). It is the installers responsibility to identify and protect all entrapment zones.

Entrapment is the condition when an object or person is caught or held in a position that increases the risk of injury. An Entrapment "zone" is any area of the Vertical Pivot Gate system that entrapment can occur.

GATE CONSTRUCTION INFORMATION ASTM F2200

Vehicular gates should be installed in accordance with ASTM F2200: Standard Specification for Automated Vehicular Gate Construction. For a copy, contact ASTM directly at 610-832-9585 or www.astm.org.

GENERAL REQUIREMENTS

1. Gates shall be constructed in accordance with the provisions given for the appropriate gate type listed, refer to ASTM F2200 for additional gate types.
2. Gates shall be designed, constructed and installed to not fall over more than 45 degrees from the vertical plane, when a gate is detached from the supporting hardware.
3. Gates shall have smooth bottom edges, with vertical bottom edged protrusions not exceeding 0.50 inches (12.7 mm) when other than the exceptions listed in ASTM F2200.
4. The minimum height for barbed tape shall not be less than 8 feet (2.44 m) above grade and for barbed wire shall not be less than 6 feet (1.83 m) above grade.
5. An existing gate latch shall be disabled when a manually operated gate is retrofitted with a powered gate operator.
6. A gate latch shall not be installed on an automatically operated gate.
7. Protrusions shall not be permitted on any gate, refer to ASTM F2200 for Exceptions.
8. Gates shall be designed, constructed and installed such that their movement shall not be initiated by gravity when an automatic operator is disconnected, in accordance with the following:
 - Vehicular horizontal slide gate. Shall not result in continuous, unimpeded movement in either lineal direction of its travel.
 - Vehicular horizontal swing gate. Shall not result in continuous, unimpeded movement in either direction along the arc of its path of travel.
9. For pedestrian access in the vicinity of an automated vehicular gate, a separate pedestrian gate shall be provided. The pedestrian gate shall be installed in a location such that a pedestrian shall not come in contact with a moving vehicular access gate. A pedestrian gate shall not be incorporated into an automated vehicular gate panel.

SPECIFIC APPLICATIONS

1. Any non-automated gate that is to be automated shall be upgraded to conform to the provisions of this specification.
2. This specification shall not apply to gates generally used for pedestrian access and to vehicular gates not to be automated.
3. Any existing automated gate, when the operator re-

quires replacement, shall be upgraded to conform to the provisions of the required standard in effect at that time.

VEHICULAR VERTICAL PIVOT GATES


1. The following provisions shall apply to Class I, Class II and Class III vehicular Vertical Pivot gates:
2. All openings or leading edge of a Vertical Pivot gate operator that pass by any fixed stationary objects while traveling open or closing, shall be designed, guarded or screened to prevent a 2 ¼" (57mm) sphere from passing through or entering the protected area designed to prevent entrapment.
Exception: All other fixed stationary objects greater than 16" (406mm) from the moving gate frame shall not be required to comply with this section.
3. Horizontal and Vertical frame members of a gate shall be smooth and shall not include protrusions other than gate hardware.
4. All gates shall be designed with sufficient lateral stability to assure that the gate will enter a receiver guide.
5. Class IV vehicular horizontal Vertical Pivot gates shall be designed, constructed and installed in accordance with security related parameters specific to the application in question.

SECTION 2 — TERMS, STANDARDS AND SPECIFICATIONS

GLOSSARY OF IMPORTANT TERMS

Operator	The mechanical device designed to open and close (raise and lower) the gate/barrier
Operator Arm	The steel tubing member of the operator the gate is bolted to and lifts the gate/barrier
Slide Assembly	An adjustable mechanism located on the operator arm that the extension springs attach to and by adjusting up and or down adds or subtracts tension to balance the operation of opening and closing of the gate panel.
Hand	The orientation or direction in which a gate assembly faces. Gate operator manufacturers determine the “Hand” of the operator by standing on the Private side of the gate entrance looking out.
False Panel	The exterior covering of the operator that typically faces the public side of the installation and provides protection from the moving gate/barrier.
Transport/Maintenance Pin (T/M)	Used to secure the Operator Arm when there is no gate attached. Also is used as a safety lock open/closed device during service work.
RAD (Right Angle Drive)	½ HP Motor Drive utilizing locking worm gear technology. The motor shaft and output shaft are oriented at 90° from each other. This type of drive provides for smoother operation throughout the gate movement cycle and is not back drivable.
Manual Operation Release Lever	Used to disengage the Right Angle Drive (RAD) from the belt drive system to allow manual opening or closing of the gate panel.
LPS (Limit/Position Sensor)	An electronic position sensor mounted on the main pulley drive shaft that provides gate position feedback to the control board. This component provides two separate features: 1. Type “A” inherent entrapment protection which safeguards against obstructions that may block and stop the gate travel. 2. Provides “open” & “close” limit positions
Genesis Control Board	The main circuit board that processes the inputs and outputs to control the overall operation of the gate.
Kick Panel	The panel under the doors to prevent anything from getting under the operator including hands, feet & rodents.

OPERATOR DETAILS



1	OPERATOR FRAME	Main operator frame, 2" sq. steel tube construction
2	THROAT	Area between the operator and false panel where the gate opens up
3	TRANSPORT/MAINTENANCE PIN (T/M)	Used for locking the arm in place with or without the gate attached
4	OPERATOR ARM	Main 2" x 4" steel tube where the gate attaches
5	STAINLESS STEEL FOOTPADS	No messy rusty footpads
6	KICK PANEL	Prevents access under the operator and debris out
7	24VDC 90° RIGHT ANGLE DRIVE MOTOR (RAD)	1/2hp Gear motor drive to ensure safe and smooth operation
8	MANUAL OPERATION RELEASE LEVER	Disengages the coupler and allows the gate to be raised by hand
9	MOTOR DRIVE BELTS	(3) High quality "A" Section cogged belts...
10	MOTOR DRIVE BELT TENSIONER	One shown, total of two
11	GATE BELT TENSIONER (Not shown, behind #12)	Allows you to tighten the belts (Not shown behind the Drive Pulley)
12	INTERMEDIATE DRIVE PULLEYS	Provides high torque to move the gate
13	GATE DRIVE BELTS	(2) High quality V-belts to move the gate
14	MAIN GATE DRIVE PULLEY	Provides high torque to move the gate
15	LIMIT/POSITION SENSOR (LPS) (behind #28)	Digital Sensor that sets the open and close locations of the gate
16	SLIDE ASSEMBLY	Adjust the balancing up or down on the threaded rod (not pictured)*
17	T-BOLT ASSEMBLY	Fine tuning of the balancing
18	CHAIN TENSIONING BOLT ASSEMBLY	Roller chain attaches here
19	#80 ROLLER CHAIN	Connects the springs to the Chain tension Bolt
20	SPRINGS (Qty. will vary on gate size and weight)	Depending on gate size & weight, you can have 2 to 8 springs
21	REAR SPRING BARS	Attaches the springs, Qty. will vary on the # of springs
22	BATTERIES ((2) required, not supplied)	Min. 7Ah batteries, recommend Group 24 100Amp Marine Starting
23	BATTERY TRAY/POWER SUPPLY (Under Battery tray)	Main Power Supply is mounted under the Battery Tray
24	3Amp AC Fuse	AC Supply fuse
25	AC/DC MAIN ON/OFF SWITCH	Turns on both the AC and DC power in one switch
26	INCOMING AC VOLTAGE JUNCTION BOX	Normally 120Vac, 240Vac compatible
27	FAULT LIGHT	Three flash modes: 1. Fault, 2: DC Power issue, 3: AC power issue
28	CONTROL BOX	Houses the Genesis control board and other accessory items
29	GENESIS CONTROL BOARD	State of the art control board with 4-line digital display
30	UL325 SIREN	Will be activate upon an UL fault
	* See Balancing Instructions for Slide details	



VERTICAL PIVOT GATE SYSTEM

MODEL VPG2490

SPECIFICATIONS

General Information

UL 325 7th Ed. Listed & CAN/CSA C22.2 No. 247-14 Listed
Rated for Continuous Duty Cycling

Power Supply Options: 120VAC—Single Phase, 20 Amp Service. 240VAC—Single Phase, 10 Amp Service. Solar.

Batteries & Charging System: Built-in Battery Backup. Two 12v Batteries Required (Field Supplied). Recommended Batteries: Group 24, Sealed Marine Starting

Gate Limit/Position Sensor (LPS): Combined Type "A" Entrapment protection. Open and Close Limit Position.

Open/Closing Speed: 8-10 seconds Std. Oversized (heavy Duty) gate speed of 14-16.

Shipping Weight: Typical VPG2490 Operator with 6' high x 20' long picket style gate = 1,500 - 1,800 lbs.

Warranty: Residential (5 years), Industrial/Commercial (3 years) from date of shipment on manufactured components workmanship. Purchased components and accessories are covered under their respective warranties. (See full warranty for details)

Optional Accessories: Solar Panels, Gear Motor Heater, Extreme Cold Package, MUTCD Reflective Tape, LED Warning lights, Audible Devices, and Emergency Access Systems (SOS, Opticom, Click to Enter, Key Box/Switch, etc.)

Transport Maintenance Pin (T/M): used for transport, maintenance to negate movement of gate panel).

Motor & Drive System

RAD (Right Angle Drive): 1/2 HP, Gear Type, Right Angle Locking Worm Drive. Equipped with disengage lever for Manual Operation.

Multi Belt/High torque dual reduction system, Counter Balanced for smooth operation.

Operator

Construction: Frame - 2" Sq., 11 Ga. (.120). Mounting pads—304 SS. Skins - 18 Ga. Galvaneal.

Gate Mounting Hardware: 304 Stainless Steel

Operator size: 68" Length, 53" Height, 30" Width

Paint: Standard Color - Black, powder coated. Spray applied colors are Commercial Coating 2-part High Solids Polyurethane. **Standard Spray Colors:** White, Brown, Green, and Gray. Custom colors available.

Genesis™ Control Board

Solid State coated programmable control board in an NEMA 4 electrical enclosure (Tested to -40° F).

Security Breach Protection: Built in 24V brake when A/C or battery is present. Optional internal locking Solenoid mechanism.

Monitored Inputs: Open - 2 inputs, Close - 2 inputs with an (2) additional programmable inputs for Open or Close.

Programmable Inputs, Outputs, & Relays: The board has 2 programmable inputs, 2 programmable outputs, and 2 built in relays for configuration and integration.

Control Wiring: 16 & 18 Ga. Single conductor. Copper with electronic compression terminals tin-plated for max corrosion prevention.

Dual Gate Operation: Programing allows for dual gate operation and Sally-Port configuration.

Delayed Closing: Programmable from 0 - 90 seconds.

Preemptive Signal outputs: 1-5 seconds before gate moves.

Gate Construction

Gate Construction: 10' - 20' - 2" Sq., 11 Ga. (.120) Steel Tubing. Over 20' - 2 1/2" Sq., 7 Ga. (.187) Aluminum Tubing.

Gate Lengths: 10' - 25' (Consult factor for over 25')

Gate Heights: 4' - 8' from pad grade. Consult factory for gates over 8' high as they require special crating and freight arrangements.

Picket Construction: Steel— 3/4" Sq. 18 Ga. Galvanized Tubing is standard. Aluminum—3/4" Sq. 1/8" wall is standard. Note: Contact factory for special sizes, spacing, and custom materials.

Chain Link Construction: 2 3/8" Sch. 40, 20 & 2" x .065" Galv. Steel Tubing 9 Ga. Galv. Fabric (12' up to 22'). 2 3/8" Sch. 80, 40 & 2" x 1/8" 6061 Alum. Tubing 9 Ga. Alum Fabric (over 22' to 25').

Wind Bracing: Cable -75 mph design, 1/4" coated aircraft cable (16' 20' gates). Rigid Masted - Gates over 20' or certain heights and materials. Compliant with IBC Section 1609.6 Simplified Wind Load Method for 90 mph wind loading and the 150 mph hurricane wind loading.

Paint: Spray applied colors are Commercial Coating 2-part High Solids Polyurethane. **Standard Spray Colors:** Black, White, Brown, Green, and Gray. Custom colors available. **Powder coating available:** Max length of 25' and max height of 7'.

TYPICAL LAYOUTS W/CONDUIT RECOMMENDATIONS

TYPICAL SINGLE GATE INSTALLATION

LOOP DETAILS:

Typical size: 6' x 10'

Max width: 6' x 20'


Custom sizes available

Minimum 4' from the gate

TYPICAL TYPES:

- **Reversing:** reverses the gate
- **Free Exit:** Opens the gate
- **Arming:** Activates Access Controls
- **Shadow:** Holds gates open (Swing gates)
- **Close:** Closes a gate (normally Barrier Arms)


120 V POWER SUPPLY
COMMUNICATIONS



Typical conduit runs:


1. AC Power Supply (20 AMP Circuit)
2. Communication to office (if applicable)
3. Photoelectric Sensor Low Voltage Power (if applicable)
4. Reversing Loop Homeruns
5. Free Exit Loop homerun (if applicable)
6. Keypad/card/phone signal & power (if applicable)
7. Gate to Gate Communications (Dual gate or Primary/Secondary system)

TYPICAL DUAL GATE INSTALLATION



TYPICAL LAYOUTS W/CONDUIT RECOMMENDATIONS


TYPICAL PRIMARY/SECONDARY INSTALLATION



Typical conduit runs:

1. AC Power Supply (20 AMP Circuit)
2. Communication to office (if applicable)
3. Photoelectric Sensor Low Voltage Power (if applicable)
4. Reversing Loop Homeruns
5. Free Exit Loop homerun (if applicable)
6. Keypad/card/phone signal & power (if applicable)
7. Gate to Gate Communications (Dual gate or Primary/Secondary system)

TYPICAL DUAL GATE INSTALLATION




SECTION 3 — INSTALLING YOUR VERTICAL PIVOT GATE SYSTEM


TOOLS AND EQUIPMENT RECOMMENDATIONS

- ◆ Lifting Strap
- ◆ Hammer & Level
- ◆ Grease Gun, Lithium Grease
- ◆ Screwdriver Sets (Flat & Phillips)
- ◆ Electrical Tape, Wire Cutters/Strippers
- ◆ Misc. Electrical Connectors
- ◆ Chalk Line
- ◆ Multi-Meter (DCV & AMPS)
- ◆ Hammer Drill, 1/2 & 5/8 Bits
- ◆ Tape Measure
- ◆ 1/2" Drive Socket Set: 1/2", 9/16", 3/4", 15/16", 1-1/8"
- ◆ Open End Wrenches: 1/2", 9/16", 3/4", 15/16", 1-1/8"
- ◆ Batteries: (2) 12 VDC Group 24 Deep cycle marine starting

RECOMMENDED CONCRETE FOUNDATION OPTIONS




1. PAD DEPTH SHOULD BE BELOW LOCAL FROST DEPTH
2. TOP OF PAD MUST BE FLAT AND LEVEL
3. USE REBAR THAT CONFORMS WITH LOCAL CODES OR PROJECT SPECIFICATIONS
4. REBAR MUST BE INSTALLED 6"-8" BELOW TOP SURFACE.
5. CONCRETE COMPRESSIVE STRENGTH MINIMUM 3000 PSI
6. DRAWING IS FOR REFERENCE ONLY, SUPERCEDED BY LOCAL AND SITE GOVERNING CODES



1. TOP PAD DEPTH SHOULD BE 10"-12" THICK
2. (5) AUGERED 12"Ø HOLES SHOULD BE BELOW LOCAL FROST LINES
3. TOP OF PAD MUST BE FLAT AND LEVEL
4. USE REBAR THAT CONFORMS WITH LOCAL CODES OR PROJECT SPECIFICATIONS
5. REBAR MUST BE INSTALLED 6"-8" BELOW TOP SURFACE
6. CONCRETE COMPRESSIVE STRENGTH MINIMUM 3000 PSI
7. DRAWING IS FOR REFERENCE ONLY, SUPERCEDED BY LOCAL AND SITE GOVERNING CODES

LEFT AND RIGHT HAND STANDARD PAD & CONDUIT

LEFTHAND OPERATOR



PRIVATE/SECURED SIDE

TYPICAL CONDUITS (Use 3/4" conduit or larger)

- ◆ 120Vac, Minimum 20Amp Circuit
- ◆ "Entrance" Keypad/Reader
- ◆ "Exit" Keypad/Reader
- ◆ Reversing Loop(s)
- ◆ Free Exit Loop(s)
- ◆ Office Communication
- ◆ Reversing Beam
- ◆ Optional


NOTES:

- 1) Pad Dimensions can vary per site
- 2) Leave at least 3" between Anchors and edge of pad
- 3) All pads must be level and below local frost line

RIGHTHAND OPERATOR

CONDUIT LOCATION/STUB-UP ON OUTSIDE OF OPERATOR PAD 12"

PUBLIC SIDE



TYPICAL CONDUITS (Use 3/4" conduit or larger)

- ◆ 120Vac, Minimum 20Amp Circuit
- ◆ "Entrance" Keypad/Reader
- ◆ "Exit" Keypad/Reader
- ◆ Reversing Loop(s)
- ◆ Free Exit Loop(s)
- ◆ Office Communication
- ◆ Reversing Beam
- ◆ Optional

NOTES:

- 1) Pad Dimensions can vary per site
- 2) Leave at least 3" between Anchors and edge of pad
- 3) All pads must be level and below local frost line

SECTION 4—RECEIVING AND UNLOADING YOUR VERTICAL PIVOT GATE SYSTEM

Gate operator and gate can be delivered assembled but are commonly delivered in two separate crates. Crated operators are assembled and ready for the gate to be attached with supplied hardware.



CAUTION: ALWAYS INSPECT ALL ITEMS FOR DAMAGE BEFORE THE DRIVER LEAVES!

DOCUMENT ANY DAMAGE ON THE DELIVERY RECEIPT.

DO NOT DROP THE GATE OR THE OPERATOR FROM THE TRUCK!


Common Carrier Delivery Unloading Tips

- Always request a delivery service with lift gate delivery trucks (not available for “volume” shipments, (3) or more gates)
- Use the lift gate or a fork lift to lower the operator
- Be sure to use leveling jacks (if available) to support weight of operator on tail lift
- ***Do not stand under or near operator while lifting***



Use “cut out” cardboard hole for lifting strap positioning

- Use a fork lift or similar device with a nylon lifting strap to off load the gate
- With lift gate in raised position gate can be positioned partially out of the truck
- ***POSITION GATE SO THAT EXISTING CUT OUT FOR LIFTING IS JUST OUTSIDE THE TRUCK***



- ***Do not stand under or near gate while lifting***


ATTACHING YOUR GATE TO THE OPERATOR

Carefully remove Gate operator and gate from packaging. Locate the cabinet door keys hanging on the Transport/Maintenance Pin (T/M). Any accessories and necessary fasteners are packaged inside the operator.




WARNING: DO NOT REMOVE TRANSPORT/MAINTENANCE PIN UNTIL GATE HAS BEEN BOLTED TO THE OPERATOR ARM AND THE OPERATOR IS SECURELY ANCHORED ACCORDING TO INSTRUCTIONS BELOW. OPERATOR ARM IS UNDER EXTREME TENSION LOAD AND REMOVING PIN COULD LEAD TO SERIOUS INJURY OR DEATH. IF AUTOGATE ATTACHED THE GATE AND OPERATOR PRIOR TO DELIVERY, INSPECT ALL BOLTS FOR TIGHTNESS.

1. Install Gate on Operator Arm.
2. Use (1) SS 3/4"-10 x 4 1/2" (STEEL GATE) or (1) SS 3/4"-10 x 5" (ALUMINUM GATE) Apply Never Seize to ALL SS bolt threads. Use (4) SS 1/2 x 1-1/2" Bolts for the lower mounting connection.
3. Insert the top bolt first and then the bottom four (4) bolts finger tight. Be certain gate is properly aligned before tightening. Tighten bottom bolts first, then tighten top bolt.
4. Linkage Arm is zip tied in the throat for shipping.
5. Locate Linkage Pivot Bolt kit (5/8" x 2-1/4") and follow the assembly diagram below. Tighten bolt to the gate lug hole. You may have to push down on the gate to insert Linkage Bolt.



WARNING: NOT FOLLOWING ASSEMBLY INSTRUCTIONS MAY CAUSE SERIOUS INJURY OR DEATH AS WELL AS DAMAGE TO THE GATE OR OPERATOR.




PARTS LIST	
#	DESCRIPTION
1	5/8-11 ZINC PLATED FULL HEX NUT
2	5/8" HEAVY WASHER
3	5/8" S.S. FLAT WASHER
4	5/8-11 x 2-1/4" LARGE HEX BOLT
5	5/8" DIA. 5/8-18 FEMALE ROD END
6	3/4" x 2" x 4" LUG
7	5/8-18 HEX NUT
8	LINKAGE ARM

LIFTING AND POSITIONING YOUR ASSEMBLED GATE AND OPERATOR

NOTE: It is recommended to attach Gate to Operator Arm before lifting (for better balance), but it is not mandatory. If using a Forklift to position Operator only, *lift from sides only!*


Do not try to lift gate and operator together from the side!

Use a lifting strap to lift Gate & Operator. The strap should be secured around Operator Arm and T/M Safety Pin or the top rail of the gate near the operator arm.



NOTE: ATTACHED GATE AND OPERATOR ARE NOT BALANCED AND WILL LEAN WHILE BEING LIFTED IN THIS MANNER. DO NOT ATTEMPT TO MANUALLY STABILIZE GATE OR OPERATOR.

- 1) Place Gate & Operator Assembly on pad so the end of the Gate is centered over the Yoke pad or intended yoke position for the site (for yoke styles mounted to posts, buildings, etc.). Allow a minimum three (3") inches from edge of the operator pad to anchor bolt holes to prevent concrete damage.
- 2) Position and align Yoke and center under gate on the pad, to a post or wall.
- 3) Secure Operator with (1) 5/8" dia. Wedge Bolt in rear; check alignment on pad as well as gate panel alignment before installing (4) remaining anchor bolts.
- 4) Secure Yoke with four (4) 1/2" dia. Anchor bolts (provided). If installing a Ground Yoke, allow a minimum space of two (2") inches between bottom of Gate and Yoke.



MANUAL OPERATION OF THE GATE

DO NOT ATTEMPT UNTIL THE OPERATOR HAS BEEN ANCHORED TO THE CONCRETE PAD!




WARNING: DO NOT REMOVE TRANSPORT/SAFETY PIN UNTIL GATE AND OPERATOR ARM HAVE BEEN ATTACHED ACCORDING TO INSTRUCTIONS. SPRINGS AND OPERATOR ARM ARE UNDER LOAD AND REMOVING PIN COULD LEAD TO SERIOUS INJURY OR DEATH.


MANUAL OPERATION RELEASE PROCEDURE

WARNING! DO NOT ATTEMPT TO MANUALLY OPEN AN MOVING GATE!

1. ROTATE THE **RED** HANDLE UNDER THE GEARMOTOR TO DISENGAGE THE DRIVE COUPLER.
2. REMOVE TRANSPORT/SAFETY PIN IF IT IS IN PLACE (behind Operator Arm) AND HANG ON THE HOOK PROVIDED.
3. IF GATE IS IN THE CLOSED POSITION, LIFT UP ON THE LINKAGE ARM WHILE HOLDING THE GATE. THE GATE IS UNDER SPRING TENSION AND WILL WANT TO TRAVEL OPEN.
4. MANUALLY PUSH THE GATE TO OPEN TO THE DESIRED POSITION AND MOVE THE **RED** LEVER BACK INTO PLACE. MOVE THE GATE UP OR DOWN SLIGHTLY TO LOCK THE COUPLER BACK IN PLACE.
5. IF THE GATE IS FULLY OPEN YOU CAN ALSO INSERT THE TRANSPORT/SAFETY PIN AND LOCK THE GATE OPEN.




MANUALLY MOVE GATE TO DESIRED POSITION. RETURN RELEASE LEVER TO ENGAGE COUPLER AT NEW POSITION. GATE WILL SELF LOCK.




MASTED WINDBRACING

CABLE WIND BRACING





MASTED WIND BRACING



GATE GUARDS

1	GATES OVER 9' TALL WILL REQUIRE LOCAL FENCING (SEE ATTACHED SHADED AREA)
2	AUTOGATE PROVIDES GATE GUARDS FOR 9' TALL AND UNDER THAT ARE CONSTRUCTED OF STANDARD MATERIAL. NON-STANDARD MATERIALS MAY NOT HAVE A PROVIDED GUARD. IF GUARD IS NOT PROVIDED: REVIEW YOUR ORDER AND DWG, CONTACT AUTOGATE.
3	FENCE OFF ALL AREAS PER F2200
4	INSTALL EXTERNAL ENTRAPMENT PROTECTION DEVICES TO MITIGATE POTENTIAL OF ENTRAPMENT.



SECTION 5—OPERATOR ELECTRICAL

The AutoGate Genesis control board is DC powered as is the motor/gate controller with built in full battery back-up. Primary power is supplied by an AC rectified output power supply (see below). Input AC is supplied through a dedicated 20 Amp breaker. Voltage is selectable, 90~132 VAC / 180~264 VAC via slide switch. This protects the Genesis controller from random or storm induced power surges on while AC power. The Earth Ground connection on the board is to aid in surge protection and random voltage issues.


NOTE: There is NO AC power inside the Control Board Enclosure!

A/C POWER CONNECTION





WARNING: ALL 120VAC OR 240VAC ELECTRICAL CONNECTIONS FROM SERVICE PANEL TO THE GATE OPERATOR MUST BE MADE BY A LICENSED ELECTRICIAN!

- Run AC power lines through conduit to junction box (see below) located inside the operator. (see typical conduit locations drawings page 14. Contact AutoGate for Optional routing).
- All AC power and control wiring MUST be run in separate conduits.
- Before doing any wiring inside the operator ensure that the main power source has been disabled at the main circuit breaker. If this is a **SOLAR** application, ensure the power input is disconnected.
- The Power Supply will be wired at the factory, you only need to wire the AC into the supplied junction box.




AC Junction Box

Rectified Power Supply
(Mounted under the
battery shelf)



P11




EARTH GROUND AND LIGHTNING PROTECTION


Install an approved 8' earth ground rod 6" to 3' off the rear side of operator pad*. The Ground wire connection is located inside the door. Recommended wire is #8 gauge or larger. **NEVER splice the ground wire!**

Improper grounding will make the operator more susceptible to lightning or surge damage and can affect GENE-SIS Board or accessories.

To Operator



*Check national and local codes for proper depth.




BATTERY WIRING AND INSTALLATION

The Genesis controller has a built-in battery charging system that has multiple formats. The charging sequence can handle full size flooded batteries as well as sealed lead acid or AGM batteries. The Genesis primary input voltage can also be connected directly to solar panel(s) for non-AC operation. The built-in charger when programmed for solar will allow the system to run off the batteries and will still charge them during the daylight hours.


Install Two (2) 12 VDC Batteries (**Required, not provided**) on the battery shelf. AutoGate recommends Group 24, 80-100 Amp Hour Deep Cycle Marine Starting batteries for extended battery back up. At a minimum use (2) - 7AH batteries for battery back up.

BATTERIES MUST REST IN A LEVEL POSTION ON THE BATTERY TRAY TO AVOID ACID LEAKING FROM BATTERIES.





Typical 24V series connection

- 1) Jumper wire from battery 1 NEGATIVE is connected to battery 2 POSITIVE.
- 2) Wire from battery 1 POSITIVE to POSITIVE terminal on control board
- 3) Wire from battery 2 NEGATIVE to NEGATIVE terminal on control board.



Batteries will charge when AC power or Solar Panels are present and power gate automatically without any changes in wiring. **Note:** Solar applications will require a program selection in the board menu (see page 28.)

SECTION 6—GENESIS CONTROL BOARD




Note: **P1** is NOT USED on the VPG2490 model. The VPG2490 uses a **Limit Position Sensor (LPS)**. **P1** would only be used if you were to install the GENESIS board in an older operator with limit switches.

P14— Loop Rack Accessory Wiring harness port: Used with our LR-3 Loop Rack board

J1-USB For data connection

P6-Program Plug: Used to update board software

VPG-2490 WIRING DIAGRAM



* OPTIONAL ACCESSORY COMPONENTS

NOTICE THE INFORMATION CONTAINED ON THIS DOCUMENT IS CONFIDENTIAL. ANY DISSEMINATION, UNAPPROVED BY THE ISSUING OFFICE, OF THIS INFORMATION IS STRICTLY PROHIBITED.	AutoGate Gate Entry Systems Berlin Heights, Ohio FAX (419) 588-3514	
	Date:	8/18/18
	Dr. By:	EGS
	Ckd. By:	.
DO NOT SCALE UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES ANGLES ± 1° XX ± .125, XX ± .01, XXX ± .004	Dwg.: AGS Genesis Board Wiring Schematic.dwg	
	Title: VPG-2490 Wiring Diagram	
	Rev.:	Description:
	1	

E:\GENESIS BOARD\PRODUCTION\GENESIS BOARD WIRING SCHEMATIC.DWG

GENESIS CONTROL BOARD

OVERVIEW: The Genesis board has a 4 line 20 characters per line LCD backlit screen. At power up, the display will show the AutoGate and Genesis branding, along with the program version number and the current time. After 5 or 6 seconds, this will then shift to the HOME screen, or base operational data shown below under MAIN SCREEN.

AutoGate Ver.7.3
GENESIS 01:22am

TITLE SCREEN

Line Voltage 25.39*
Batt Voltage 26.67
Motor 0.00 Amp
Cycles 0 T=00

MAIN SCREEN

Open Time: 10
Close Time: 10
>Auto Close: Off<
Auto Delay: 03

Example 1

Open Time: 10
Close Time: 10
Auto Close: Off<
Auto Delay: 03

Example 2

JOG/SELECT Control Knob: The screens are accessed and modified by a JOG/SELECT control knob. Turning the Jog/Select dial will scroll through the sub-menu selections. When a Sub Menu is showing, a quick momentary press of the Jog/Select knob will display the first screen in that sub menu. Turning the Jog/Select knob will move the cursor (>) through the adjustable parameters.



JOG/SELECT Knob

SCROLLING: Rotating the Jog/Select knob clockwise will scroll through the adjustments on that screen. If there is another screen in that sub-section, continue to scroll after the last character, the screen will automatically change to the next screen. When at the last screen of a sub-section, a long push, (approx. 1 second), of the Jog/Select knob will return to the Sub-Section main screen. Sub Sections can be scrolled in either direction by turning the Jog/Select knob clockwise or counter-clockwise.

JOG/SELECT ACTIONS: Two different actions can occur on the screens:

- 1) If the cursor is pointed to a descriptive phrase (Example #1), then a momentary push of the Jog/Select knob will move the cursor to the adjustable parameter. Then turning the Jog/Select knob will change the value.
- 2) When the cursor is pointed to left side of a value or parameter to be changed, (example #2), use quick momentary push of the Jog/Select knob to move the cursor. The cursor will move to the right side of the value (<). Turning the Jog/Select knob will change the value. When done, again, a quick momentary push of the Jog/Select knob moves the cursor back to the left.

Note: Gate will not be operational while in programming mode. When in programming mode there will be a series of flashing lights at all times above the LCD screen.

Note: Screens in ORANGE are **WARNING** screens that will appear when there is an issue.

SCREEN MENUS

MAIN SCREEN

Line Voltage 25.39*
Batt Voltage 26.67
Motor 0.00 Amps
Cycles 0 T=00

Line voltage: From the Power supply. (Normal voltage will be 26 to 27, Preset to 26.5Vdc)

Battery voltage: When AC present: Charging Voltage to batteries, When on DC only: Actual battery voltage. (Normal voltage is 26.4 to 26.8)

Motor: Displays actual motor amperage during cycling

Cycles: A cycle count is considered a complete **OPEN & CLOSE**

T=00: Operation count in seconds for both open and close cycles and also counts down the "Timer to Close" (**CLOSE TIME**) time.

CALENDAR/TIME

Calendar/Time

Set the time, date and day of the week.

GENESIS CONTROL BOARD

CALENDAR/TIME (cont.)

>01:14:58 am
03/21/19 Th

Set the time, date and day of the week.

TIMER SETTINGS

Timer Settings

TIMER SETTINGS: 4 Sub Menus to set OPEN & CLOSE times, Motion ALARM times and 7-DAY TIMERS

>Open time: 10
Close Time: 10
Auto Close: off
Auto Delay: 03

OPEN/CLOSE TIME: Full Speed Run Time, Set this when the slow down is to start. Slows down after time value expires. *This option is only active when LIMIT SWITCHES are used.*

AUTO CLOSE TIME: Default is **ON** from 1 to 90 seconds, **OFF** requires a **CLOSE** command.

CLOSE TIME DELAY: Timer to close after all inputs are clear. Settable from 1 to 90 seconds.

>Motion Alarm: On
Pre-Op Alarm: 0
Pre-Close Alarm: 0

MOTION ALARM: Turns ON and OFF an alarm or Strobe Light.

PRE-OPEN ALARM: Turns on the alarm from 1 to 5 seconds *before* the gate opens.

PRE-CLOSE ALARM: Turns on the alarm from 1 to 5 seconds *before* the gate closes.

***Note:** This time value must be equal to or shorter than the AUTO CLOSE TIME value.

>Automatic Schedule:
Off

AUTOMATIC SCHEDULE: Sets the gate to lock OPEN and CLOSE daily, 7 Days a week, Monday thru Friday or Saturday & Sunday only

Automatic Schedule:
>7 days a week

Automatic Schedule:
>Mon-Fri only

Automatic Schedule:
>Sat & Sun only

Automatic Schedule:
>Custom-Daily

Set the time, date and day of the week individually. Two complete options for each day: SUNDAY to SATURDAY and SUNDAY 2 to SATURDAY 2.

Monday
>On
Open: 08:00 am
Close: 06:00 pm

Each day has the ability to set a HOLD OPEN and CLOSE time.

Thursday 2
OFF<
Open: 06:00 am
Close: 05:00 pm

(Same as above) Each day has the ability to set a **second** HOLD OPEN and CLOSE time.

GENESIS CONTROL BOARD

MONITORED INPUT SETTINGS

Monitored Input Options

OPTIONS: OPEN OBSTRUCTION, CLOSE OBSTRUCTION, PROGRAMMED MONITORED INPUTS:

Choices are: 10K (10,000 Ohms Resistance) or 2-Wire.

(The Genesis board supports a maximum number of (2) OPEN, (2) CLOSED & (2) programmable inputs. Contact AutoGate if additional inputs are required).

WARNING Monitored Input missing
See LED indicators For Monitored

Board is programmed for a "Monitored" Input and it is missing, gate will not operate until the monitored input is restored.

Open Obstruction:
>Edge: 10K
Beam: Off

OPEN OBSTRUCTION: You have (3) choices: **OFF**, **10K** or **2-WIRE**. You must have a minimum of (1) programmed at all times for UL325 Rev. 6 and up.

WARNING! Obstruction
An intended Input or manual reset req'd. to restore use.

If your gate had an OPEN OBSTRUCTION event, the gate will stop and reverse to full close until the obstruction is cleared and an INTENDED INPUT (Access Control Input, Loop Reset, etc., but *NOT* the CLOSE TIMER) or a MANUAL INPUT on the control board resets your gate back to normal operation.

Close Obstruction:
>Edge: Off
Beam: 10K

CLOSE OBSTRUCTION: You have (3) choices: **OFF**, **10K** or **2-WIRE**. You must have a minimum of (1) installed and programmed at all times per UL325 Rev. 6 through latest editions. **CLOSE OBSTRUCTION DEVICES** are approved Beams and Edges only!

WARNING! Obstruction
An intended Input or manual reset req'd. to restore use.

If your gate had a **DOUBLE CLOSED EDGE OBSTRUCTION** event, the gate will shut down in the OPEN position until the obstruction is cleared and an INTENDED INPUT (Access Control Input, Loop Reset, etc., but *NOT* the CLOSE TIMER) or a MANUAL INPUT on the control board resets your gate back to normal operation.

Prog Mon Input 1:
>Open Edge 10K
Prog Mon Input 2:
Close Beam 2-Wire

PROGRAM MONITORED INPUTS: Additional INPUTS for additional monitored devices. Choices are: **OFF**, **10K**: OPEN EDGE, OPEN BEAM, CLOSE EDGE & CLOSE BEAM
2-WIRE: OPEN EDGE, OPEN BEAM, CLOSE EDGE & CLOSE BEAM.

WARNING! Obstruction
An intended Input or manual reset req'd. to restore use.

If your gate had an OBSTRUCTION event, depending on the monitored device, the gate will shut down either in the OPEN or CLOSED position until the obstruction is cleared and an INTENDED INPUT (Access Control Input, Loop Reset, other) or a MANUAL INPUT on the control board will reset your gate back to normal operation.

INPUT OPTIONS

Input Options

OPTIONS: INPUT 1 & 2

GENESIS CONTROL BOARD

INPUT OPTIONS (cont.)

>Input 1 Mode:
Off
Input 2 Mode:
Off

**WARNING! FIRE
SWITCH IS ENABLED.
Hold Stop and press
Joa/select to clear**

**WARNING! HOLD OPEN
IS ENABLED, gate
will not close
until released**

**WARNING! EMERGENCY
SECURE is enabled.
Gate will not OPEN
until released**

>Aux Input 1 Delay
5 Seconds
Aux Input 2 Delay
0 Seconds

>Open/Close Pgm In:
Off

INPUT (1 & 2) MODES:

OFF

OPEN-Open command

CLOSE-Close command

Single Button-Open-Stop-Close-Stop

Reverse-Reverse command

Fire-Holds the gate Open (*will cause a FLASHING ALERT warning screen*)

Shadow-Shadow Loop input

Auto Open: Default is OFF-Skips the next days 7-Day Timer cycle commands

Hold Open-Opens gate: Holds open until Input removed (*will cause a FLASHING ALERT warning screen*)

Emergency Secure-Gate will NOT open (*will cause a FLASHING ALERT warning screen*)

Emergency Close-(Custom programmed, contact AutoGate for this option)

Aux 1 Pulse-Pulses Auxiliary 1 contacts

Aux 1 Hold-Holds Auxiliary 1 contacts until triggered

Aux 2 Pulse-Same as Pulse 1

Aux 2 Hold-Same as Hold 1

AUXILLARY INPUT 1 & 2 DELAY: Option to delay the INPUT from firing and opening the gate. Settable from 1 to 20 seconds

Open/Close Program: Programs the OP/CL PRM Input under P2 on the board to either and OPEN/CLOSE Input or an OPEN only.

AUXILARY OUTPUT OPTIONS

Aux Output Options

>Relay A Mode:
Off
Relay B Mode:

OPTIONS: AUXILIARY RELAYS (A & B), OUPUT (1 & 2), PROGRAMMABLE LOCK

AUXILIARY RELAYS (A & B): Either relay can be set for a variety of functions:

OFF

Pulse on Open Limit

Pulse on Close Limit

Hold on Open Limit

Hold on Close Limit

Pulse on Motor Open

Pulse on Motor Close

Hold on Motor Open

Hold on Motor Close

>Output 1 Mode:
Hold on Aux 2
Output 2 Mode:
Off

OUTPUT (1 & 2): Either relay can be set for a variety of functions and provides 24vdc power

OFF

Pulse on Open Limit

Pulse on Close Limit

Hold on Open Limit

Hold on Close Limit

Pulse on Motor Open

Pulse on Motor Close

Hold on Motor Open

Hold on Motor Close

Hold on UL Alarm

Hold on Motor Run

GENESIS CONTROL BOARD

AUXILIARY OUTPUT OPTIONS (cont.)

>Programmable lock:
Magnetic
Aux Output states:
Out1 N-0, Out2 N-0

PROGRAMMABLE LOCK: Output to control Maglocks or Solenoid Locks. The Maglock will be powered all the time and turn off prior to gate motion. The Solenoid mode will power a 24VDC output prior to gate motion.

>Output 1 Pulse Rate
2 Seconds
Output 2 Pulse Rate
¼ Seconds

OUTPUT PULSE RATE:

MAINTENANCE

Maintenance

GATE ORIENTATION, BATTERY STATUS, SOLAR, BATTERY CHECK, BATTERY LEVEL, OVER CURRENT LEVEL, CONSTANT PRESSURE MODE, DUAL GATE MODE & CUSTOM SETTINGS

>Gate Orientation:
Right

GATE ORIENTATION: Set for LEFT or RIGHT hand gate. The hand is always determined from the INSIDE or PRIVATE side of the gate system. If the operator is located on the right-RIGHTHAND, left-LEFTHAND.

>Dual Gate Mode:
>Off
Status
Disconnected

DUAL GATE MODE: Turn "ON" when you have (2) gates opening at the same time.
Options: OFF, Primary or Secondary. If "ON", then each gate needs to be set accordingly
STATUS: Disconnected or Connected

Dual Gate Mode
Communication lost

In a PRIMARY/SECONDARY or DUAL gate mode system, if you lose communication between the two operators you will get this message.

Batt: Float Charge
>PWR SUPPLY: Normal
Batt V Check Freq:
50 Cycles

BATTERY STATUS: Indicates the charging status:
FLOAT: When battery is FULL voltage and not being charged
BULK: Battery is in charging mode
ABSORPTION: Batteries are low, switches to charging

POWER SUPPLY VOLTAGE:

NORMAL (Default): Standard power supply

CHARGE: For retrofitting older systems only and replaces the original factory transformer

SOLAR: Used when you have Solar Panels

WARNING! If Solar is set to ON, and AC voltage is present, the AC voltage will not be connected and you will still be operating off batteries only!

Loss of **SOLAR** or **Power Supply** connection for 24 hours **(will cause a FLASHING ALERT warning screen)**

BATTERY V CHECK: How often the board will test the batteries under load. The factory pre-set is every 50 cycles. (Pass code required to change cycle frequency)

>Low Battery Action
No Action

LOW BATTERY ACTION: Default is No Action

Options are:

FAIL SAFE: Gate will fail OPEN **(will cause a FLASHING ALERT warning screen)**

FAIL SECURE: Gate will fail CLOSED. **(will cause a FLASHING ALERT warning screen)**

WARNING! FAIL SAFE!
Gate held OPEN due
to critical low
battery voltage

WARNING! FAIL SECURE
Gate held CLOSED due
to critical low
battery voltage

GENESIS CONTROL BOARD

MAINTENANCE (cont.)

>Low Battery Level
*Note: this screen
not viewable.
Requires passcode*

BATTERY LEVEL: During battery test, if the battery level falls below the level set, it will turn on the **FAULT LIGHT** and issue a **FAULT CODE**. (Passcode required to change). *(will cause a FLASHING ALERT warning screen)*

WARNING! LOW BATTERY
Check charge
circuit, charge or
replace Batteries

Battery issue: Check the charge voltage, check the Batteries or replaced if necessary.

>Over-Current level:
10 Amps

OVER-CURRENT LEVEL: Adjusts the Internal Inherent Amp current level for the motor. On model 2490 systems with the GENESIS board and the **LPS SENSOR**, this will not be in effect. When using **LIMIT SWITCHES**, the **OVER-CURRENT LEVEL** must be set for obstruction/entrapment sensing. If the board senses an OVER-CURRENT it will reverse the gate on the first activation. On a sequential activation, this will stop the gate and turn on the UL Alarm. To reset.... Check for any obstructions, if none, Press the STOP button on the board or if you have an accessory STOP button wired to the STOP input. The third option is to hit the RESET button.

>Const Press Mode:
Off
On with STOP N-O
On with STOP N-C

CONSTANT PRESSURE (CP) MODE (CLASS IV): In the CP mode, the **OPEN 1 & CLOSE 1** inputs can be wired to a push button station for gate control. In a CP mode, these inputs will override the Entrapment **STOP/ALARM** condition. Status is **ON** or **OFF** only.

WARNING! Use caution when using these inputs. Always have direct line of site to the gate at all times to avoid pedestrian injuries or equipment/vehicle damage.

LOCKED
Key: EB60F3CA
- - - - -

CUSTOM SETTINGS: For advanced features. Requires a "PASSCODE" available from AutoGate only. Code is active for 24 hours only. After 24 hours a new code is required.

MOTOR CONTROL

Motor Control

OPTIONS: GATE SPEED, LIMIT SWITCHES, HALL (A & B), OPEN/CLOSE, POSITION SETTINGS

>Gate Opening Speed:
100%
Gate Closing Speed:
100%

GATE SPEED: Default 100%, any percentage less than 100% down to 80% will slow the gate opening and closing down accordingly.

>Open Decel: 10
Close Decel: 10

DECEL SPEED: Sets the time value on setting the gate speed from full speed to slow speed. The scale is 1 to 20, with 20 being the slowest.

GENESIS CONTROL BOARD

MOTOR CONTROL (cont.)

>Limit Switches:
Not Used

LIMIT SWITCHES: Default is "NOT USED". Model VPG 2490 systems are equipped with a **Limit Position Sensor (LPS)**. *If no sensor is present, then a fault code is generated and the gate will not move.* Choices are: **NORMALLY OPEN, NORMALLY CLOSED, HALL & HALL B**. Normally open & close will choose the type of wired Limit Switch to be used.

HALL A & HALL B: Only used on direct replacements on **LIFTMASTER/MEGA ARM** operators.

WARNING! No Limit
Position Sensor
detected! Gate will
not operate!

FAULT/LOGS/ALERTS

Fault/Logs/Alerts

OPTIONS: Fault log, Operation Log, Maintenance Alerts

Fault Log
>25 10:34p 04/20/18
Gate Angle Sensor

FAULT LOG: Running list of faults, stored for reference for diagnostic troubleshooting. The last 99 codes are stored. The newest code will always be the first one shown. Any fault in the system will also turn on the **FAULT LIGHT** on the outside of the cabinet.

Operation Log
#06< 02:55p
06/29/18
Local Open

OPERATION LOG: All normal "operations" are recorded up to 99 events. (i.e. entry Inputs, loop detections, & photoelectric sensors/beam detections, traffic lights, etc. are examples of normal "operation" events logged.)

>Maintenance Alerts
50K Cycles
Next due at 80,000

MAINTENANCE ALERT: Alerts the owner that maintenance is due after a selected number of cycles. This can be set by the installer for 10K, 20K or 50,000 cycles. The screen will show how long until the next alert will show. **NOTE: WILL THERE BE SCREEN FLASHING TO ALERT FOR MAINTENANCE?**

>Maintenance Alert
Maintenance required

MAINTENANCE ALERT: You have reached your predetermined number of cycles to perform general maintenance.

SECTION 7—ENTRAPMENT PROTECTION DEVICE INSTALLATION AND WIRING

NOTE: The operator will not operate without the minimum entrapment devices installed! You must have ONE Type “A” and ONE Monitored Type “B” installed in both the OPEN and CLOSING directions.

The Genesis controller is equipped with Type “A” inherent obstruction sensing and has 6 monitored entrapment inputs. The monitored inputs will be initially programmed at factory but are field selectable. There are edge and beam inputs for both “Open” and “Close” directions. **Please note that a minimum of one “open” and one “close” approved monitored entrapment device must be present along with one Type “A” device for the gate operator to function.** There are 2 programmable monitored inputs for open or close, and either can be edge or beam. All inputs are capable of 10K or 2-wire pulse, and will be programmable in the field. Any additional entrapment areas must be protected in a similar way with approved monitored devices.

APPROVED PROTECTION DEVICES FOR THIS OPERATOR

Type B1 (non-contact) devices

Open or Opening

Your Vertical Pivot operator now requires a minimum of ONE OPEN obstruction device to be wired to the Genesis Control board to operate. You may use any approved device listed below. The face and the throat area are required to be protected per UL325 7th edition.


The Genesis board supports use of a maximum of four type B1 devices.

- Open Beam
- Close Beam
- (2) Programmable Inputs


Close or Closing

Photoelectric sensors/beams should be positioned within 4” of the moving gate where risk of entrapment is identified. If using only one close beam locate within 18” of road surface.

Approved Non-Contact Devices: EMX IRB-Mon, EMX IRB-RET & OMRON EK3



MONITORED DEVICE CONNECTIONS POINTS



ENTRAPMENT PROTECTION DEVICE INSTALLATION AND WIRING


Type B2 (contact)

Contact Sensors

Close or Closing

Contact edges on the bottom of the gate are often added as an extra entrapment device for the closing mode. We do not recommend a contact edge to be the only external entrapment device for the closing mode.


- Open Edge
- Close Edge
- Programmable Inputs (x2)





Approved Edge Sensor Devices: Miller Edge CPT 223, ASO SENTIR 15-10VT, 45 STKS4

Open or Opening

Your Vertical Pivot operator now requires a minimum of (1) OPEN obstruction device to be wired to the Genesis Control board to operate. You may use any approved device listed above. The face and the throat area are required to be protected per UL325 7th edition.



MONITORED DEVICE CONNECTIONS POINTS





NOTE: The two programmable inputs can be configured as either edge or beam and as either open or close.

ENTRAPMENT PROTECTION DEVICE FUNCTIONAL CHARACTERISTICS

Monitored Open Edge	When activated, the gate will stop, (in less than 2 seconds), and then reverse and go to a full close secured position. Gate will remain closed until it receives an "INTENDED" INPUT (Keypad/Reader/Push Button/Free Exit) or the board is manually reset (Not from an Entrapment input).
Monitored Open Beam	When activated, the gate will stop, (in less than 2 seconds), and then reverse and go to a full close secured position. Gate will remain closed until it receives an "INTENDED" INPUT (Keypad/Reader/Push Button/Free Exit) or the board is manually reset (Not from an Entrapment input).
Monitored Programmable Input 1 & 2	Choice of Open or Close direction by Menu, choice of Edge or Beam and then 10K or 2 wire by Menu. <i>(Refer to PROGRAMMABLE INPUT FUNCTIONAL descriptions for required action.)</i>
Monitored Close Edge	When activated the first time, the gate will stop in less than 2 seconds, and reverse to full open and allow the 'Timer To Close' to be activated upon open limit. Upon the second activation closing, before reaching the close limit, the gate will again stop, (in less than 2 seconds), and reverse to full open and the 'Timer To Close' will be deactivated. The gate will remain at full open until an "INTENDED" INPUT is activated (Keypad/Reader/Push Button/Free Exit) . The close command will close the gate and clear the hold command. An 'Open' command or a "Reverse" command, (not the Close Beam input) will trigger the reset of the 'Timer To Close' activation. Also, any of the action buttons on the control board can activate the gate, (Close button will close gate and the Open & Stop buttons will reset the 'Timer To Close' to be active). Note: Upon the second activation before reaching the close limit, when the gate is in the "HOLD" condition, any input that was being maintained at the time of the second activation shall be ignored until the gate is enabled by a different input! If the CLOSE EDGE remains activated, no input will release the gate for operation.
Monitored Close Beam	When activated, the gate shall stop in less than 2 seconds, and then reverse to full open. The 'Timer to close' will become active only after all inputs are clear.
UL Alarm	In the event the gate receives sequential obstructions, the UL Alarm will activate. To clear, verify that there are no obstructions in the movement path of the gate. Reset the gate by pressing the STOP button on the board or pulse the STOP accessory button input. If the gate keeps stopping with alarm activation, check the balance, verify that the OVER CURRENT setting is high enough to allow normal operation of the gate. On a 2490 system, make sure the LPS is functioning properly.



OPERATIONAL RELAYS

In addition to the entrapment sensor inputs there are operational inputs for vehicle detection, communication with another gate or similar device as well as push buttons for control of various modes of operation.



INPUT NAME	FUNCTION AFTER MOMENTARY TRIGGER	FUNCTION DURING CONTINUOUS TRIGGER
Shadow Loop	While at open limit, hold open, ignore once off of the open limit switch. <i>(Not common on Vertical Pivot Gate)</i>	Hold Open
FE/Back (Free Exit/ Back Away)	Opens gate as Open1, but when signal is removed, gate is given command to close. (Close command over ridden by any other open or Reverse/Interrupt command or stop command) (Primarily designed to work with FE/Back on Barrier Arms)	Starts opening movement from any position
Close Loop	Start closing movement from any position, Open commands can override. If gate is closing when activated, gate stops until clear and then continues to close. Close input responds on release of the input normally. Close input will hold the gate open while input is maintained with the gate in the open position. When in constant pressure mode, close input responds on initial press. <i>(Not common on Vertical Pivot Gate)</i>	If held in upward motion, no effect. If held in downward motion, gate movement is paused until released and continues downward on release
Reverse/Interrupt	When closing, stops and re-opens.	If held, stay open
Open / Close PGM	When menu option not enabled, Input = open 1 only. When enabled, input = Open 1 unless the open limit is reached, it then turns to Close. If input is held during OPEN, gate holds open. Input needs to cycle off before input can CLOSE gate.	If held it remains in its state
Open 1	starts opening movement from any position	starts opening from any position
Open 2	starts opening movement from any position	Same as above
Fire Open	Absolute open, until the board is hard power reset, or local reset button pushed	Locks gate open until released
Stop	Stops gate at any point and cancels current inputs. Inputs will be ignored until stop is released. A stop input will disable the auto-close timer	If held, no gate movement, inputs ignored.

OPERATIONAL OUTPUTS





Warning Light	Four States OFF: No faults FAST Blink: Low battery voltage DOUBLE PULSE Blink: Loss of AC power SLOW Blink: Any other fault <i>priority for the signals are:</i> 1 - Low battery 2 - Loss of AC 3 - Any other fault
Motion Alarm	Active for full cycle (ON-OFF menu selectable). Programmable for pre-movement opening (0-5 seconds menu selectable). Programmable for pre-movement closing (0-5 seconds menu selectable).
UL325 Alarm	Active for conditions related to UL325 specifications
Lock	Programmable/Selectable: Magnetic lock option - Active when the gate is closed. Solenoid Interlock option - Momentary activation to open the bolt that mechanically latches the gate closed.
Input 1	OPTIONS: OFF, OPEN, CLOSE, Single Button, Reverse, Fire, Shadow, Auto Open, Hold Open, Emergency Secure, Auxiliary Pulse 1 & 2, Auxiliary Hold 1 & 2
Input 2	Same as INPUT 1
Output 1 (24VDC)	OPTIONS: OFF, Pulse on Open or Close Limit, Hold on Open or & Close Limit, Pulse on motor Open or Close, Hold on Motor Open or Close, Hold on UL Alarm, Hold on Motor Run
Output 2 (24VDC)	Same as Output 1

OPERATIONAL OUTPUTS

P12

P13



AUX Relays A & B: Are programmable for operation based on gate action or position. Both relays are form "C" relays that can be programmed to change state based on gate position or motion.

AUXILIARY RELAYS A & B

OPTIONS:

OFF

Pulse on OPEN Limit: 2-second Relay Activation

Pulse on CLOSE Limit: 2-second Relay Activation

Hold on OPEN Limit: Latches Relay ON during OPEN Limit

Hold on CLOSE Limit: Latches Relay ON during CLOSE Limit

Pulse on Motor OPEN: 2-second Pulse when gate starts to move OPEN


Pulse on Motor CLOSE: 2-second Pulse when gate starts to CLOSE

Hold on Motor OPEN: Latches Relay on when gate is OPENING


Hold on Motor CLOSE: Latches Relay ON when gate is CLOSING

POWER FOR EXTERNAL DEVICES

The Genesis board has (2) 24VDC outputs and (2) 12VDC outputs to power external devices. Each is fused at 2 AMPS.




P9



24VDC	ACCESSORY Power	(2) Fused at 2 Amps total
12VDC	ACCESSORY Power	(2) Fused at 2 Amps total

COMMUNICATIONS AND POSITION SENSOR

Primary/Secondary communications allow for communications between gates for Dual Gate configurations.




PRIMARY/SECONDARY OR DUAL GATES

When using two gates to cover a driveway and they both need to cycle together on an open input. Connect the two boards with a 4-conductor SHIELDED 18 ga. wire (3 required, 1-spare) and set the following board parameters:

>Dual Gate Mode:
Off
Status:
Disconnected

P/M: Set for Primary /Secondary communication. Gates need to communicate with each other to work properly.



LIMIT/POSITION SENSOR (LPS)


Your gate is equipped with a LIMIT/POSITION SENSOR. It will be properly set when it leaves the factory. If you need to adjust it, refer to the instructions below. If you need to replace, contact AutoGate.

ADJUSTING THE LIMIT/POSITION SENSOR

>Op:4500 Ramp:4000
Gate 1
Cl:430 Ramp:950
Op Sp:10 Cl Sp:10

WARNING! This screen requires a PASSCODE to access.

1. In programming mode, Set your cursor to the GATE (line 2) and enter (>Gate). Using the Jog knob you can slightly adjust the OPEN or CLOSE position by turning it left or right.
2. Once you have readjusted your gate position, "enter" again to back out of the Gate line and go up to the **Op:** line or down to the **Cl:** line to set your new numbers.
3. "Enter" (op or CL) and turn the jog knob to the new numbers and test your gate.



GENESIS FREQUENTLY ASKED QUESTIONS (FAQ'S)

Q. My gate will not move, and the ALARM is sounding, what should I do?

A. The gate is in the UL Fault mode. Verify that there are no obstructions in the movement path of the gate. Reset the gate by pressing the STOP button on the board or pulse the STOP input. If the gate keeps stopping with alarm activation, check the balance, verify that the OVER CURRENT setting is high enough to allow normal operation of the gate. On a 2490 system, make sure the LPS is functioning properly.

Q. What kind of power does the Genesis board run on?

A. The Genesis board runs from a 24 volt DC power supply and 24 volt battery back-up. Genesis can run directly off solar panels. The gate motor runs off the batteries and the Solar Panels will keep the batteries charged. The charging circuit is integrated on the board.

Q. How much accessory power is available?

A. The Genesis board has both 24 volt DC and 12 volt DC accessory power available. A total of 2 amps are available at 24 VDC. A separate 2 amps are available at 12 VDC.

Q. Does Genesis have monitored inputs for "Entrapment Protection"?

A. Yes, there are 6 monitored inputs. Two dedicated inputs for the closing direction, (1-beam, 1-edge), and two dedicated inputs for the open direction, (1-beam, 1-edge). There are two fully programmable inputs that can function in either direction and for either type of device. These inputs are capable of monitoring 10K ohm devices. ***Note: there must be at least one (1) device connected in both the open and close direction in order for the gate to operate.***

Q. Is there a way to monitor the gate position, (Open or Closed)?

A. Yes, there are 2 Auxiliary relays on the board which can be used. Also there are 2 Auxiliary Outputs which can output 24 Volts DC to accessories when open and/or closed.

Q. Can the board control external devices, such as traffic lights, counters, and other options?

A. Yes, the 2 Auxiliary relays are programmable to trigger based on gate position and/or motion.

Q. Can the speed of the gate motion be controlled ?

A. Yes, the speed of the gate can be controlled separately in both directions. The adjustment will be from 100% to 75%.

Q. Why is the Green LED light flashing?

A. The green flashing LED signifies that the processor is powered up and working. If LED is on steady or OFF, the processor has a problem and the board needs replaced.

Q. System is completely dead and will not operate, how do I open the gate?

A. In a catastrophic failure (blown board, total power loss, etc.), pull the release handle on the bottom of the motor drive mechanism to disengage the drive coupler. Then at the gate, lift the Linkage Arm slightly upwards. The springs will start to pick the gate up. Then, push up on the bottom of the gate until fully open. Insert the T/M pin to lock open.

FREQUENTLY ASKED QUESTIONS (FAQ'S)

Q. What is the difference between the “FAULT” log and the “OPERATIONAL” log?

A. The “Fault” log will store failures that are not part of standard operations. This includes things like no device connected to an active monitored input, or loss of voltage from the power supply, low battery voltage during the battery test, etc. The Operational log records all input actions, like the Open Input activation, or a monitored device is activated. This log also records the actions like close activation from the auto timer.

Q. Can I download the logs?

A. Yes, the logs will be available to download by the USB port.

Q. My gate is not working, and a row of LED's is flashing?

A. The row of flashing LED's indicates the control board is in a programming mode and will not allow the gate to move. The control board will automatically cycle out of programming mode after 1 minute of no activity by the Jog/Select knob.

Q. What do I do if the “Main Power Loss / Low Battery” LED is flashing?

A. This LED is a multifunctional indicator. There are 3 flash rates that will display. If the LED is flashing, there is either a “Main Power” loss, a “Low Battery” condition, or a system fault. Open the outer cabinet door and look at the control board, a “Fault Screen” will display the current situation or fault.

Q. My gate closes too fast. How do I slow it down?

A. There are several possibilities:

1. The gate may be out of balance. Once the gate has been rebalanced or determined to be “In” balance, if necessary, the closing speed can be adjusted.
2. Adjust the slowdown time longer
3. Change the overall running speed of the gate in the closing direction

To access these adjustments will require a PASSCODE. Adjusting the “DECEL” rate shorter will slow the gate down faster, thereby slowing the overall speed. To adjust the closing speed, access the screen showing the gate speed, which will have both Open & Close speed adjustable. The speed will be adjustable from 85% to 100% in 5% increments. Our recommendation would be to slow the gate down to 95% and test. This will normally be enough for most installations. If necessary, adjust to 90%.

Q. Why won't my gate run in it is in programming mode?

A. This is a safety feature. Sudden gate motion while programming could cause a unintended reaction by the service technician that could lead to an injury. The only time the gate can move in program mode is during the program screen while setting Limit Switches. There is the ability to move the gate in minute increments by turning the JOG/SELECT knob while the “GATE” option is chosen on the screen.

TROUBLE SHOOTING THE GENESIS BOARD

Alarm is sounding and gate will not run	• Gate is in UL Alarm lock out – Press the “STOP” button to clear alarm; Verify there is no obstruction in the gate path. If alarm keeps coming on, rebalance gate and check OVER CURRENT setting.
No power to control board	• Verify power switches are “ON”. • Check 20 amp fuses on control board. • Check wires, connections at power supply, 10Amp fuse & batteries.
Gate will not operate	• Make sure Limit/Position Sensor (LPS) is connected and Genesis can see the signal. • Verify that there is at least one monitored device in both the open and close direction connected and operating correctly. • Check that both the batteries and power supply are on and the correct voltage is available to the board. • Check wiring connections at the motor; verify they are clean and tight. • Make sure the motor manual operation release disconnect is engaged for operation.
Gate starts to move then stops and/or reverses	• Check fault Log • Verify motor over current value is set properly. • Check and adjust gate balance. • If gate reverses when closing, check for any input activation. • If gate reverses when opening, check for any “Open Entrapment” input activation.
Gate will not close	• Check Fault log • Check operation inputs for activation, clear as necessary. • Verify “Close Monitored Inputs” are connected properly and functional. • Check for Reversing or Free Exit loop or detector fault.
Gate will not open	• Verify “Open Monitored Inputs” are connected properly and functional.
Gate opens, will not time out to close	• Verify “Auto Close” is on. • Use “Close” command to close gate. If gate closes, gate was in second close edge obstruction and was awaiting an input to activate motion.
Batteries will not charge up	• If running on the AC Power Supply, make the board is not set for SOLAR operation. Verify that the power supply has an output voltage of $26.5 \pm .5$ volts. • If running on SOLAR panel(s), make sure board is set for SOLAR operation. Verify the panel(s) have an output greater than 31 volts DC.
Red LED light on side of Cabinet is flashing	• The RED LED is a warning light. If flashing, indicates a fault or failure. • Fast Flash – Low Battery • Double Pulse Flash – Main Power input Missing • Slow Flash – Fault or UL Alarm


MAINTENANCE

The basic electrical and mechanical systems require only minimum routine maintenance. The following items should be checked and serviced periodically depending on amount of use. Each item below has supporting illustrations and/or instructions in this manual. Contact AutoGate for any questions or issues. **Maintenance is important to any gate system and can affect safety, warranty, quality operation, and life-cycle of the system.**

REFER TO OPERATOR DETAILS PAGE 10 AND MAINTENANCE OPERATOR DETAILS ON PAGE 43

ITEM	RECOMMENDED MAINTENANCE
Grease Linkage Assembly ("LUBRIPLATE 'R' LOW TEMP" Grease)	10,000 cycles or 6 months
Grease all bearings: two (2) Operator Arm, four (4) Bullwheel Shafts	10,000 cycles or 6 months
Grease Chain Tension Bolt and Lube Chain & lightly coat springs (Use a non-evaporating cable and chain spray)	10,000 cycles or 6 months
Check belts for wear and tightness. (See page 44 for instructions)	Every 6 months
Charge voltage for batteries should be 27.5 VDC with batteries disconnected check at battery in maintenance menu.	Every 6 months
Check battery water level, use distilled water only (Not required on maintenance-free or AGM style batteries)	Every 6 months
Clean snow/ice off of gate (Balanced correctly, gate will temporarily tolerate an additional 10 lb. of wt.)	As needed
Clean lenses on Photoelectric sensors/beams or Reflectors	As needed
Lubricate (Graphite Oil) all door latch, lock cylinders and mechanisms	Every 6 months
Check and verify proper operation of all External monitored entrapment protection devices. See page 22 and the external entrapment protection device (s) manufactures instructions.	Every month
Check and verify proper operation of the Internal (TYPE A) entrapment protection device (LPS) by walking to the middle to end of the gate and stop the gate, it should reverse.	Every month
Check gate balance (see page 46)	Four months after install, then annually
Check to make sure all WARNING signs are still displayed	Every month

MAINTENANCE OPERATOR DETAILS



ELEVATION VIEW

Note: P/M Details only, see other pages for details on electronics and accessories.


BELT CHANGING INSTRUCTIONS

Changing the belts on an AutoGate Vertical Pivot operator is easy by following the step by step procedure outlined below. As always, we are only a phone call away should you need assistance at 800-944-4283.

1. Remove the **(4) Tek Screws** on the **Top Panel** using a 5/16" nut driver, remove and set aside.
2. Remove the **STIFFENER PLATE (#1)** from the **POSITION SENSOR bracket**. This allows a space to remove belts.
3. Release the **MOTOR DRIVE BELT (#2)** tension by loosening the **(4) 3/8" CARRIAGE BOLT nuts** securing the **GEAR MOTOR bracket (#3)** to the **SIDE SLIDE plates (#4)** with a 9/16" wrench. Now using a 9/16" wrench, back off the **(2) Gear Motor FORCING screws (#5)** so that only 1" remains through the coupling nut.
4. Slide the **GEAR MOTOR assembly** to create slack in the belts.
5. On the center of the pulleys. Loosen the **FLANGE BEARING bolts (#6)** about one turn that secure the shaft bearings using a 15/16" wrench.
6. Loosen the **MIDDLE FORCING screw (#7)** which is applying tension on the **GATE DRIVE belts (#8)** by using a 15/16" wrench. This too needs to be fully loosened to allow enough room to remove the belts.
7. Remove old belts and install new belts loosely.
8. Apply snug pressure to the **MOTOR DRIVE belts** by using the **(2) GEAR MOTOR FORCING screws**. This should also snug the **GATE DRIVE belts**. *Do not overtighten!*
9. Thread the **MIDDLE FORCING screw** to finger tight.
10. Re-Assemble the **STIFFENER PLATE** to the **POSITION SENSOR bracket**.
11. Operate the gate up and down for (5) time to seat the belts.
12. Tighten the **MIDDLE FORCING screw** to tighten the **GATE DRIVE belts**. Correct tightness is 10lbs. of pressure applied at the center of belts with a 1/2" deflection.
13. Tighten the **FLANGE BEARING bolts** on the middle set of pulleys.
14. Tighten the **GEAR MOTOR FORCING screw** to achieve 1/4" deflection with 10lbs. of pressure applied at the center of the belts.
15. Tighten the **(4) CARRIAGE bolts** to secure the **GEAR MOTOR bracket** to the **SIDE SLIDE plates**.
16. Operate the gate up and down 5-10 times to check for proper operation.
17. Replace the **Top Panel** using the (4) **Tek screws**.

BELT TIGHTENING INSTRUCTIONS

- | | |
|---------------------|------------------------------|
| 1. Stiffener Plate | 5. Gear Motor Forcing Screws |
| 2. Motor Drive Belt | 6. Flange Bearing Bolts |
| 3. Gear Motor | 7. Middle Forcing Screw |
| 4. Side Slide | 8. Gate Drive Belts |



SPRING CHANGING INSTRUCTIONS



WARNING: SPRINGS ARE UNDER A TREMENDOUS LOAD. TAKE EXTREME CAUTION WHEN REMOVING AND REPLACING THEM.

TOOLS REQUIRED: 5/16" (Nut Driver), 1/2", 1 1/8", 1 5/16" Open End Wrenches


STEPS:

1. For ease of access, remove the door and end panel nearest the gate.
2. Disable the photoelectric sensor/beam if equipped.
3. Remove any upper "T" bolts completely and loosen the slide assembly screws.
4. Loosen the top adjusting nut of the slide assembly. Thread the nut up to within four (4") inches of the top of slide mechanism.
5. You will now raise the gate. (**DO NOT** release the disengage lever!) Initiate the gate to open, immediately move to the gate and help raise it open, once the slide moves up, hold on the bottom rail of the gate until fully open. The gate may bounce slightly, there will be a loud bang but no damage will occur.
6. Turn Off AC/DC Power before gate "times out" and tries to close. Insert T/M Pin.
7. Using a 1 5/16 wrench, loosen and remove the chain tension bolt with the damaged spring.
8. Replace damaged spring
9. Replace chain tension bolt. **NOTE:** Grease fitting must point down! Tighten bottom nut. **NOTE:** Chain **MUST** remain level and not twisted once tightened.
10. Remove T/M pin and restore AC/DC power.
11. Lowering the gate. Initiate the gate to close and at the same time, assist the gate down by pulling on the bottom rail of the gate. The slide will move down and another loud bang as the gate is lowered.
12. Turn off AC/DC power.
13. Thread the slide nut back down to the slide assembly and tighten.
14. Replace the T-Bolts to their original location and tighten and tighten the slide assembly screws.
15. Restore AC/DC power and hook photoelectric sensor/beam back up.
16. Cycle gate.

17. Spray all springs with a chain lube to prevent corrosion.

18. Grease Chain Tension bolts, Linkage Arm & Bearings

RECOMMENDED: Always check and adjust the balance after any spring change. Refer to balancing instructions at www.AutoGate.com or the instructions on Page 46




BALANCING

TESTING AMPERAGE

1. Connect AMP meter in series by removing the wire nut from the **RED** motor lead.
2. Cycle gate up and down recording the highest amperage in the space provided and adjust in necessary. highest UP and DOWN readings should not exceed a 1 AMP difference. For example: If your highest reading is 6.5 UP and 6.0 DOWN, that would be acceptable. Unacceptable would be 3.1 UP and 8.0 DOWN.

ADJUSTING:

1. Loosen the set screws on the Slide Assembly as well as the 1 1/8" nuts on both sides (top & bottom) of the Slide Assembly Angle.
2. Only adjust the nuts 3 to 4 turns (1/4") at a time and check your amperage readings after each adjustment.
NOTE: your amps in the OPEN mode should be approximately .5 (1/2) amp higher than the CLOSE amperage.
3. If the gate opens too slow and is drawing high amps, raise the Slide Assembly and recheck. If the gate will NOT close, lower the Slide Assembly and re-check. If your gate stalls in either direction, you have over-adjusted. Back off the last adjustment and re-check.
4. If the gate is slow starting to close from the open position, increase the length of the T-Bolt (s).
5. Tighten Set Screws and 1 1/8" nuts.



UP: 10% 55% 85%

Down: 10% 55% 85%