

RETROFIT INSTRUCTIONS TO INSTALL A GENESIS BOARD REPLACING A LIFTMASTER BOARD



LIFMASTER BOARD



GENESIS BOARD



RSP-320-27 POWER

Congratulations on your purchase of our new state of the art GENESIS control board kit for replacing the LiftMaster control board which has been discontinued.


PLEASE READ THESE INSTRUCTIONS THOURHLY BEFORE PROCEEDING.

WE HIGHLY RECOMMEND A CERTIFIED TECHNICAN REPLACE INSTALL THIS UPGRADE KIT!

Included in your kit are the following items:

- GENESIS Control Board (w/terminal blocks)
- RSP-320-27 Power Supply w/(2) mounting screws & (2) Mounting brackets
- 6' **RED** & **BLACK** wire (power from the power supply to the board-replaces **YELLOW** wires)
- 6' **BLACK** & **WHITE** AC Power wires 14 gauge (power from AC box to power supply if needed)
- 6' **GREEN** ground wire
- DC Troubleshooting light w/4' of 24 gauge 2-conductor **RED** & **BLACK** wire
- 10Amp Glass fuse (Replaces the AC 3Amp in the face of the Battery Tray)
- Miscellaneous wire connectors and cable ties


1. Turn off all power (**AC** at Outlet Box & **DC** Toggle switch under Control Box). For extra precaution, turn off the main dedicated breaker feeding the operator outlet box.
2. **CAUTION: Additional accessories may have been installed and powered off the AC transformer by a 3rd party!** These will need to be handled by the onsite technician doing the upgrade.
3. Remove transformer cover. Unplug the wires, unbolt, remove transformer, discard or recycle.



Optional location for new power supply. Fan facing out. Secure on top tubing to back skin.

Remove Transformer Cover & Transformer.

Transformer: Remove wires, Unbolt, remove transformer discard or recycle.



4. When removing the **YELLOW** transformer wires and discarding, *also* remove the small **RED** & **BLACK** wires going to the **AC POWER INDICATOR LIGHT** (If used). These wires will be re-connected on the GENESIS board "**MAIN POWER LOSS/LOW BATTERY**" & **COM** (See **P3**). The AC Indicator light will be replaced with a

DC LED FAULT light. It will FLASH where there are issues. Review the GENESIS Board menus for more details on what causes the light to flash and the different types of flashing.


5. Connect the original or supplied **AC BLACK & WHITE** wires that fed the transformer to the Power Supply using spade connectors. **BLACK** to the **L-Line**, **WHITE** to the **N-Neutral**.
6. Connect the supplied 14-gauge **GREEN Ground** wire to the power supply ground. Run the **GREEN Ground** wire along the **BLACK & WHITE** wires back to the **AC Outlet** box and connect to the AC Outlet box **GREEN Ground** wire.
7. Using the supplied new **RED & BLACK** wires connect them to the Power Supply, **RED** to positive, **BLACK** to negative.
8. The RSP-320-27 has a universal AC input switch and will accept **100-240 Vac**. Any voltage over 120 needs to be single phase. See below for proper wiring.
9. We suggest Installing the new power supply by securing it to the frame on top of the back tubing above the Battery Shelf in the same area the transformer was located but towards the corner (see above picture) using one or two of the included mounting brackets. The brackets attach to the power supply with metric M4 x 6 mm screws. Use the self-tapping screws provided to attach to the battery shelf/frame or skin.
Options: install on the back panel next to the AC outlet or installed UNDER the Battery Shelf. Make sure the fan is not blocked. **NOTE: Leave the ORIGINAL AC and DC switches in place!**

Mounting bracket & mounting holes



120 Vac	240 Vac
L-Line (BLACK)	L-Line (Black)
N-Neutral (WHITE)	L-Line (Black)
G-Ground (GREEN)	G-Ground (GREEN)
-V (BLACK)	
+V (RED)	
VOLTAGE ADJUSTMENT POT	

10. On the old LiftMaster board, Remove the **J2** terminal strip (4 terminals: Limit Switches wires) from the top left side of the board.
11. Remove the **J5** (12 terminals: Input, reversing devices & grounds) terminal strip at the top right side of the board.
12. Remove the **BROWN** wire from the **J1** terminal
13. Mark and unscrew the wires from the **J4** terminal strip at the bottom of the board.
14. Remove and save screws from side of control box mounting the control board. Then, using a pair of needle nose pliers, squeeze the tabs together on the stand-offs to release the control board.



J2: LIMIT SWITCH WIRES



J5: ACCESSORY INPUT




J4: MOTOR & POWER




Bolts

15. Remove the LiftMaster board. Align the **GENESIS** board over the stand-offs and push down to lock in place.
A small screwdriver may be used to pry open the lock tabs on the stand-offs.
16. Using the original screws and nuts, attach the mounting bracket to the side of the control box.
17. Attach BATTERY **RED** & **BLACK** wires to the **P11** terminal marked **BATTERY +/-**. *Leave the 24 VDC MAIN POWER toggle switch in the battery positive wire.* This will allow turning the batteries on/off without having to remove wires.
18. Attach the **DC RED** & **BLACK** power supply wires from the power supply to the **24V DC** terminals on the **P11** terminal strip. Make sure to follow the correct polarity!
19. Attach the Motor wires to the MOTOR A/B terminals
20. Wires: **RH OPERATOR MOTOR: A=BLUE, B=ORANGE. LH OPERATOR MOTOR: A=ORANGE, B=BLUE**



P11



21. Attach the **RED** & **BLACK ACCESSORY POWER STRIP** wires to the **P9** terminal strip (24VDC). **RED** to POSITIVE, **BLACK** to COMMON.





P9



P1

22. Transfer the limit switch wires from the LiftMaster terminal strip **J2** to the **GENESIS P1** terminals (see above) **LIMIT** input terminals. These will be in the same position. Left end wire is the **WHITE OPEN** limit wire. The second terminal is the **RED CLOSE** limit wire. The third terminal is for the 2 **Black** wires (commons) from the limit switches. **WARNING! DO NOT TURN ON ANY POWER AT THIS TIME!**
23. Remove wires from the **J5** 12 terminal strip taken from the LiftMaster board earlier. One by one insert them in their proper location on the **GENESIS P2** terminal strip (see below). Any wires that were in terminals #1, #2, or #3 on the **J5** LM board, put into Open 1 or Open 2. Any wire in terminal #4 on the **J5** LM board, put into the **OP/CL PGM**. Wires located in terminal #5 on the **J5** of the LM board will be put into **REV/INT**. If there is a wire in the **J5** #6, move it to the **CLOSE** input on **GENESIS**. Normally, the **FE/BACK** & **SHADOW** are not used. If they are, use the same input as marked on **GENESIS**.




P2

20. Now attach the **BROWN** wire into the 6th terminal down on the **P3** terminal strip on the left side of the **GENESIS** board. This is the UL alarm wire. The ground for the alarm is already wired to the ground on the auxiliary power strip to the left of the board. If there is an auxiliary limit switch kit, the power wires for this will be removed from the LM BATTERY terminals and attached to the **24 VDC & COM** terminals on the **P9** (see graphic above) terminal strip.



FAULT LIGHT CONNECTION

COMMON

MAIN POWER LOSS/LOW BATTERY



P3




J2: LIFMASTER PRIMARY/SECONDARY (M/S)



P8: GENESIS PRIMARY/SECONDARY

P8



21. If you are replacing both boards in a PRIMARY/SECONDARY DUAL gate system, remove the cross-connected wires between the gates, but do not reconnect yet. After connecting control wires to the GENESIS board, use 3 of the cross-connect wires for the DUAL GATE COMMUNICATION connection on **P8**. If you have a shielded multi-conductor wire cable for the connection, connect the SHIELD to a COMMON on the **PRIMARY gate only!** Then use any three remaining wires for the PRIMARY/SECONDARY connection. **A to A, B to B and C to C.**
22. **NOTE: DO NOT** re-connect the CYCLE COUNTER, AMP METER (located in the electrical box door), both of these items are built into the GENESIS board. (See screens below)
23. If you had a **VOLTAGE CLAMP ACCESSORY** board, do not re-connect it as well, just toss it.
24. **POWERING UP YOUR SYSTEM:** If main circuit breaker has been turned off, turn it back on. Turn on **AC** power switch and turn on the **DC** battery toggle switch. **Note: IF YOUR BOARD WAS FACTORY PRESET,** the board should power up and display the **TITLE** screen with the **GENESIS** Version number (Ver. #.#). After 6 to 8 seconds the screen will change to the **MAIN** screen showing the **Line Voltage (DC) from the AC/DC Power Supply, Battery Voltage (DC), Motor Amps, Cycles** and **Close Timer**. If your board was not Factory preset, you will get a **FAULT** warning screen with this message: **LPS SENSOR NOT DETECTED BY THE GENESIS BOARD!** You will need to call AutoGate (800-944-4283) for assistance in programming your board for **LIMIT SWITCH** use. **WARNING! DO NOT OPERATE YOUR GATE AT THIS TIME!**
25. Scroll down to **TIMER SETTINGS** to set the **AUTO CLOSE** if your system was set to close automatically.

AutoGate Ver A#.#
GENESIS 01:22am

Line Voltage 25.39*
Batt Voltage 26.67
Motor 0.00 Amp
Cycles 0 T=00

Timer Settings

Auto Close: Off<
Auto Delay: 03
Open Time: 10
Close Time: 10

26. Follow the enclosed GENESIS board instructions (included) to setup ALL options, accessories and reversing equipment paramaters

27. Change the **BATT:** Bulk Charge >Power SUPPLY to "NORMAL" (*may already be done by the factory*)

28. The **OUTPUT VOLTAGE POT** is adjustable between 27-31 Vdc. We recommend setting it to 29.5 volts.

Maintenance

Batt: Float Charge
>PWR SUPPLY: "Normal"
Batt V Check Freq:
50 Cycles



29. *You are now ready to fully test your gate system.*

- a. Check your board programming for to make sure you are set for LIMIT SWITCHES and your MONITORED INPUTS are all set to OFF. If not, you will need to contact AutoGate for the KEY code to change those statuses.

>Limit Switches:
Yes

Open Obstruction:
>Edge: Off
Beam: Off

Close Obstruction:
>Edge: Off
Beam: Off

- b. If your GENESIS board was **FACTORY PRESET** your operating speed should be set for **OPENING** and **CLOSING** speed of 110%, if not change the speed to 110%. Refer to **OPERATOR CONTROL/GATE SPEED** below in the GENESIS programming instructions to adjust if necessary.
- c. Now cycle the gate and record your OPENING & CLOSING cycle times.
- d. Set the OPEN RUN and CLOSE RUN times for 2 seconds LESS than the cycle times you just recorded. For example, if the cycle time was 12 seconds, set the run times to 10.

GENESIS BOARD OPERATION BUTTONS

GREEN: OPEN (Will also act as a constant pressure and override defaults to OPEN the gate)

YELLOW: CLOSE (Will also act as a constant pressure and override defaults to OPEN the gate)

RED: STOP (Stops the gate in either direction)

WHITE: RESET (Resets the board in the event of a program change or fault)

- a. Press the **GREEN** OPEN button, if you set the **CLOSE TIME** the gate should time out and close. If you have not set the **CLOSE TIME**, it is found under **TIMER SETTINGS**.
- b. Press the **YELLOW** CLOSE button to close the gate.
- c. Test **ALL** Accessory & Reversing (Photo Beams, Loops, Keypad, Card Readers, etc.) devices to make sure they are operational.

Note: There should not be any accessory indicator or warning lights on.

27. For the balance of the GENESIS board instructions and set up, please review the **GENESIS CONTROL BOARD** document attached.

28. Refer to TROUBLESHOOTING guide or for more information, go to **GENESIS** Board Instructions or 2490 Installation manual which is located online at <https://www.autogate.com/vertical-pivot-gates/> under the INFORMATION tab.

For further assistance, call AutoGate 800-944-4283 and ask for Tech help.

GENESIS CONTROL BOARD

OVERVIEW: The **GENESIS** board has a 4 line 20 characters per line **LCD** backlit screen. At power up, the display will show the AutoGate and **GENESIS** branding, along with the program version number and the current time. After 5 or 6 seconds, this will then shift to the HOME screen, or base operational data shown below under **MAIN** Screen.

AutoGate Ver. A#.#
GENESIS 01:22am

TITLE Screen

Line Voltage 25.39*
Batt Voltage 26.67
Motor 0.00 Amp
Cycles 0 T=00

MAIN Screen

Open Time: 10
Close Time: 10
>Auto Close: Off
Auto Delay: 03

Example 1

Open Time: 10
Close Time: 10
Auto Close: Off<
Auto Delay: 03

Example 2

JOG/SELECT Control Knob: The screens are accessed and modified by a **JOG/SELECT** control knob. Turning the Jog/Select dial will scroll through the sub-menu selections. When a sub-menu is showing, a quick momentary press of the Jog/Select knob will display the first screen in that sub-menu. Turning the Jog/Select knob will move the cursor (>) through the adjustable parameters.



JOG/SELECT Knob

SCROLLING: Rotating the Jog/Select knob clockwise will scroll through the adjustments on that screen. If there is another screen in that sub-section, continue to scroll after the last character, the screen will automatically change to the next screen. When at the last screen of a sub-section, a long push, (approx. 1 second), of the Jog/Select knob will return to the sub-section main screen. Sub-sections can be scrolled in either direction by turning the Jog/Select knob clockwise or counter-clockwise.

JOG/SELECT ACTIONS: Two different actions can occur on the screens:

- 1) If the cursor is pointed to a descriptive phrase (Example #1), then a momentary push of the Jog/Select knob will move the cursor to the adjustable parameter. Then turning the Jog/Select knob will change the value.
- 2) When the cursor is pointed to left side of a value or parameter to be changed, (example #2), use quick momentary push of the Jog/Select knob to move the cursor. The cursor will move to the right side of the value (<). Turning the Jog/Select knob will change the value. When done, again, a quick momentary push of the Jog/Select knob moves the cursor back to the left.

Note: Gate will not be operational while in programming mode. When in programming mode there will be a series of flashing lights at all times above the LCD screen.

Note: Screens in ORANGE are **WARNING** screens that will appear when there is an issue.

SCREEN MENUS

MAIN SCREEN

Line Voltage 25.39*
Chrg Voltage 26.67
Motor 0.00 Amps
Cycles 0 T=00

Line voltage: From the Power supply. (Normal voltage should be 29 to 30, Recommended to 29.5Vdc)

Charge/Battery voltage: When AC present: Charging Voltage to batteries, When on DC only: Actual battery voltage. (Normal Battery voltage is 26.4 to 26.8) (Normal Charging Voltage is 26.0 to 28.5 volts)

Note: * Indicates **CURRENT POWER source**

Motor: Displays actual motor amperage during cycling

Cycles/Position: A cycle count is considered a complete **OPEN & CLOSE**. Hold the Jog/Select button down and the Cycles will change and show the gate position "0" being **CLOSED** and "90" being full **OPEN**.

T=00: Operation count in seconds for both open and close cycles and also counts down the "Timer to Close" (**CLOSE TIME**) time. **NOTE:** 0-90 Display is not available with **LIMIT SWITCHES**.

CALENDAR/TIME

Calendar/Time

Set the time, date and day of the week. This is an important feature. It will affect the data in all **FAULT** and **OPERATION** logs as well as any **TIME** functions to hold the gate open on any given day(s).

GENESIS CONTROL BOARD

CALENDAR/TIME (cont.)

>01:14:58 am
03/21/19 Th

Set the time, date and day of the week.

TIMER SETTINGS

Timer Settings

TIMER SETTINGS: 4 Sub Menus to set **OPEN** & **CLOSE** times, **MOTION ALARM** times and **7-DAY TIMERS**

>Auto Close: Off<
Auto Delay: 03
Open Time: 10
Close Time: 10

AUTO CLOSE TIME: Default is **ON** from 1 to 120 seconds, **OFF** requires a **CLOSE** command.

CLOSE TIME DELAY: Timer to close after all inputs are clear. Settable from 1 to 120 seconds.

(Note: If using the "Auto Close" in a **PRIMARY/SECONDARY** gate system, *only set the PRIMARY "Auto Close" to on, leave the Secondary off*).

OPEN/CLOSE TIME: Full Speed Run Time, Set this when the slow down is to start. Slows down after time value expires. ***This option is only active when LIMIT SWITCHES are used. Set this time for TWO SECONDS less than recorded cycle time in your initial test of your gate!***

>Motion Alarm: On
Pre-Op Alarm: 0
Pre-Close Alarm: 0

MOTION ALARM: Turns ON and OFF an alarm or Strobe Light.

PRE-OPEN ALARM: Turns on the alarm from 1 to 5 seconds *before* the gate opens.

PRE-CLOSE ALARM: Turns on the alarm from 1 to 5 seconds *before* the gate closes.

***Note:** This time value must be equal to or shorter than the **AUTO CLOSE TIME** value.

>Automatic Schedule:
Off

AUTOMATIC SCHEDULE: Sets the gate to lock **OPEN** and **CLOSE** daily, 7 Days a week, Monday thru Friday or Saturday & Sunday only

Automatic Schedule:
>7 days a week

Automatic Schedule:
>Mon-Fri only

Automatic Schedule:
>Sat & Sun only

Automatic Schedule:
>Custom-Daily

Set the time, date and day of the week individually. Two complete options for each day: SUNDAY to SATURDAY and SUNDAY 2 to SATURDAY 2.

Monday
>On
Open: 08:00 am
Close: 06:00 pm

Each day has the ability to set a **HOLD OPEN** and **CLOSE** time.

Thursday 2
OFF<
Open: 06:00 am
Close: 05:00 pm

(Same as above) Each day has the ability to set a **second HOLD OPEN** and **CLOSE** time.

GENESIS CONTROL BOARD

OPERATOR CONTROL

Operator Control

OPTIONS: GATE SPEED, LIMIT SWITCHES, HALL (A & B), OPEN/CLOSE, POSITION SETTINGS

>Gate Orientation:
Right

GATE ORIENTATION: Set for **LEFT** or **RIGHT** hand gate. *The hand is always determined from the INSIDE or PRIVATE side of the gate system.* If the operator is located on the right-RIGHTHAND, left-LEFTHAND.

>Dual Gate Mode:
>Off
Status
Disconnected

DUAL GATE MODE: Turn "ON" when you have (2) gates opening at the same time.

Options: OFF, PRIMARY or SECONDARY. If "ON", then each gate needs to be set accordingly

STATUS: Disconnected or Connected

- If using the "Auto Close", only set the PRIMARY "Auto Close" to on, leave the Secondary off
- Make sure both gates are powered up, otherwise you receive a "communication" error message (see yellow message below)

Gate set in DUAL
Mode: Primary or
Secondary not
detected

In a PRIMARY/SECONDARY or DUAL gate mode system, if you lose communication between the two operators you will get this message.

Note: *Gates will not operate in DUAL gate mode unless BOTH are powered up and connected.*

>Gate Opening Speed:
110%
Gate Closing Speed:
110%

GATE SPEED: Default 100%, any percentage less than 100% down to 75% will slow the gate opening and closing down accordingly. Downward speed to fast will cause a **FAULT: SPEED OVER-RUN** (see below). *When retro fitting, set speed to 110% for both OPEN and CLOSE.*

>Limit Switches:
Not Used

LIMIT SWITCHES: Default is "NOT USED". You will need to contact AutoGate if your board was not set at the factory to **LIMIT SWITCHES** before you go received it. Choices are: **NORMALLY OPEN**, **NORMALLY CLOSED**, **HALL A & HALL B**. Normally open & close will choose the type of wired Limit Switch to be used.

>Open Decel: 10
Close Decel: 10

DECEL SPEED: Sets the time value on setting the gate speed from full speed to slow speed. The scale is 7 to 20, with 7 being the fastest and 20 being the slowest.

WARNING! No Limit
Position Sensor
detected! Gate will
not operate!

WARNING! Downward
Speed too fast.

>Const Press Mode:
Off
Stop Input Mode:
Normally Open

CONSTANT PRESSURE (CP) MODE (CLASS IV): In the CP mode, the **OPEN 1**, **OPEN 2** & **CLOSE** inputs can be wired to a push button station for gate control. In a CP mode, these inputs will override the Entrapment **STOP/ALARM** condition. Status is **ON** or **OFF** only. Default is **OFF**.
STOP INPUT MODE: Either Normally **OPEN** or Normally **CLOSED**

WARNING! *Use caution when using these inputs. Always have direct line of site to the gate at all times to avoid pedestrian injuries or equipment/vehicle damage.*

GENESIS CONTROL BOARD

MONITORED INPUT SETTINGS (NOT USED WHEN REPLACING A LIFTMASTER CONTROL BOARD-SKIP THIS SECTION!)

Monitored Input Options

OPTIONS: OPEN OBSTRUCTION, CLOSE OBSTRUCTION, PROGRAMMED MONITORED INPUTS:

Choices are: 10K (10,000 Ohms Resistance) or 2-Wire.

(The GENESIS board supports a maximum number of (2) OPEN, (2) CLOSED & (2) programmable inputs. Contact AutoGate if additional inputs are required).

WARNING Monitored Input missing
See LED indicators For Monitored

Board is programmed for a Monitored Input. If it is missing, gate will not operate until the **monitored** input is installed or restored.

"Monitored" device is enabled and the req'd feedback (10K-Pulse) is missing

Board is programmed for a Monitored Input. If it is enabled and the required feedback is missing you will get these **FAULTS: CLOSE BEAM MISSING, OPEN BEAM MISSING, CLOSE EDGE MISSING, OPEN EDGE MISSING. PGM INPUT 1 MISSING, PGM. INPUT 2 MISSING.** You will need to re-establish the monitored device.

WARNING! Obstruction
An intended Input or manual reset req'd. to restore use.

If your gate has a monitored UL Event and either "locks" open or goes "closed", this warning screen will appear as well as the **FAULT** light will flash. Any intended **INPUT** will reset the gate to normal operation. Providing the obstruction is no longer present. You can also "manually" reset the board.

Open Obstruction:
>Edge: **Off**
Beam: **Off**

OPEN OBSTRUCTION: You have (3) choices: **OFF, 10K** or **2-WIRE**. You must have a minimum of (1) programmed at all times for UL325 Rev. 6 and up.

WARNING! Obstruction
An intended Input or manual reset req'd. to restore use.

If your gate had an **OPEN OBSTRUCTION** event, the gate will stop and reverse to full close until the obstruction is cleared and an **INTENDED INPUT** (Access Control Input, Loop Reset, etc., but **NOT** the **CLOSE TIMER**) or a **MANUAL INPUT** on the control board resets your gate back to normal operation.

Close Obstruction:
>Edge: **Off**
Beam: **Off**

CLOSE OBSTRUCTION: You have (3) choices: **OFF, 10K** or **2-WIRE**. You must have a minimum of (1) installed and programmed at all times per UL325 latest edition. **CLOSE OBSTRUCTION DEVICES** are approved Beams and Edges only!

WARNING! DOUBLE DEFAULT! Push RED STOP or RESET button to restore use.

If your gate had a **DOUBLE CLOSED EDGE OBSTRUCTION** event, the gate will shut down in the OPEN position until the obstruction is cleared and an **INTENDED INPUT** (Access Control Input, Loop Reset, etc., but **NOT** the **CLOSE TIMER**) or a **MANUAL INPUT** on the control board resets your gate back to normal operation.

Prog Mon Input 1:
>Open Edge 10K
Prog Mon Input 2:
Close Beam 2-Wire

PROGRAM MONITORED INPUTS: Additional INPUTS for additional monitored devices. Choices are: **OFF, 10K:** OPEN EDGE, OPEN BEAM, CLOSE EDGE & CLOSE BEAM
2-WIRE: OPEN EDGE, OPEN BEAM, CLOSE EDGE & CLOSE BEAM.

WARNING! Obstruction
An intended Input or manual reset req'd. to restore use.

If your gate had an **OBSTRUCTION** event, depending on the monitored device, the gate will shut down either in the **OPEN** or **CLOSED** position until the obstruction is cleared and an **INTENDED INPUT** (Access Control Input, Loop Reset, other) or a **MANUAL INPUT** on the control board will reset your gate back to normal operation.

GENESIS CONTROL BOARD

WARNING Double Fault
Red Stop input or
manual reset req'd
to restore use.

If your gate had a **DOUBLE FAULT**, it will be shut down. To restore normal activity, check for obstructions and if clear, hit the **RED STOP** button, do a manual reset or power the system down and back on again.

INPUT OPTIONS

Input Options

OPTIONS: INPUT 1 & 2

All of the **INPUTS** will require a momentary pulse from a remote source such as a Pushbutton, Toggle Switch, etc.

>Input 1 Mode:
Off
Input 2 Mode:
Off

INPUT (1 & 2) MODES:

OFF

OPEN-Open command

CLOSE-Close command

Single Button-Open-Stop-Close-Stop

Reverse-Reverse command

Fire-Holds the gate Open (*will cause a FLASHING ALERT warning screen*)

Shadow-Shadow Loop input

Auto Open: Default is OFF-Skips the next days 7-Day Timer cycle commands

Hold Open-Opens gate: Holds open until Input removed (*will cause a FLASHING ALERT warning screen*)

Emergency Secure-Gate will NOT open (*will cause a FLASHING ALERT warning screen*)

Emergency Close-(Custom programmed, contact AutoGate for this option)

Aux 1 Pulse-Pulses Auxiliary 1 contacts

Aux 1 Hold-Holds Auxiliary 1 contacts until triggered

Aux 2 Pulse-Same as Pulse 1

Aux 2 Hold-Same as Hold 1

WARNING! FIRE
SWITCH IS ENABLED.
Hold Stop and press
Joq/select to clear

WARNING! HOLD OPEN
IS ENABLED, gate
will not close
until released

WARNING! EMERGENCY
SECURE is enabled.
Gate will not OPEN
until released

>Aux Input 1 Delay
5 Seconds
Aux Input 2 Delay
0 Seconds

AUXILLARY INPUT 1 & 2 DELAY: Option to delay the INPUT from firing and opening the gate. Settable from 1 to 20 seconds

>Open/Close Pgm In:
Off

Open/Close Program: Programs the OP/CL PRM Input under P2 on the board to either: OFF, OPEN only or OPEN and CLOSE.

AUXILARY OUTPUT OPTIONS

Aux Output Options

OPTIONS: AUXILIARY RELAYS (A & B), OUPUT (1 & 2), PROGRAMMABLE LOCK

AUX RELAYS will switch contact between **NORMALLY OPEN** and **NORMAMLLY CLOSED** from a common input.

AUX OUTPUTS physically switch **24VDC ON** or **OFF**

GENESIS CONTROL BOARD

AUXILIARY OUTPUT OPTIONS (cont.)

>Output 1 Quick Set:
Always Flashing
Output 2 Quick Set:
Flashing Closed

OUTPUT QUICK SET OUTPUT 1 & 2: 4 Quick Set options for flashing lights:

Choices are:

No Preset: Off

Always Flashing: Light Flash 24/7

Closed & Motion 1: Always flashes except on solid on full open

Closed and Motion 2: Always flashes except off on full open

Flashing Closed: Lights flash when the gate is closed only

>Relay A Mode:
Off
Relay B Mode:

AUXILIARY RELAYS (A & B): Either relay can be set for a variety of functions:

OFF

Pulse on Open Limit

Pulse on Close Limit

Hold on Open Limit

Hold on Close Limit

Pulse on Motor Open

Pulse on Motor Close

Hold on Motor Open

Hold on Motor Close

Note: When installing an accessory item (traffic light, siren, etc), you need to run the COMMON down to our **POWER TERMINAL** (common) and then take a wire from the **24vdc** up to the RELAY A or B COMMON. This will provide power to your unit.

>Output 1 Mode:
Hold on Aux 2
Output 2 Mode:
Off

OUTPUT (1 & 2): Either relay can be set for a variety of functions and provides 24vdc power

OFF

Pulse on Open Limit

Pulse on Close Limit

Hold on Open Limit

Hold on Close Limit

Pulse on Motor Open

Pulse on Motor Close

Hold on Motor Open

Hold on Motor Close

Hold on UL Alarm

Hold on Motor Run

Hold Always

Pulse Always

Hold Not Open Limit

Pulse Not Open Limit

Hold Not Close Limit

Pulse Not Close Limit

Hold Not Opening

Pulse Not Opening

Hold Not Closing

Pulse Not Closing

Pulse On Motor Run

Note: For all accessories (lights, alarms, etc.), check on www.autogate.com for technical data or refer to the manufacturer's technical data and installation sheets.

>Programmable Lock:
Magnetic
Aux Output states:
Out1 N-O, Out2 N-O

PROGRAMMABLE LOCK: Output to control Maglocks or Solenoid Locks. The Maglock will be powered all the time and turn off prior to gate motion. The Solenoid mode will power a 24VDC output prior to gate motion.

AUX OUTPUT STATES:

Out 1 N-O, Out 2 N-O: Normally OPEN, Normally OPEN

Out 1 N-C, Out 2 N-C : Normally CLOSED, Normally CLOSED

Out 1 N-C, Out 2 N-O: Normally CLOSED, Normally OPEN

Out 1 N-O, Out 2 N-C: Normally OPEN, Normally CLOSED

GENESIS CONTROL BOARD

AUXILIARY OUTPUT OPTIONS (cont.)

>Output 1 Pulse Rate
2 Seconds
Output 2 Pulse Rate
¼ Seconds

OUTPUT PULSE RATE: Controls the time sequence of the pulse

Options: ¼ Second, ½ Second, 1 Second, 2 Seconds

Options: 1 Second Single

MAINTENANCE

Maintenance

GATE ORIENTATION, BATTERY STATUS, SOLAR, BATTERY CHECK, BATTERY LEVEL, OVER CURRENT LEVEL, CONSTANT PRESSURE MODE, DUAL GATE MODE & CUSTOM SETTINGS

Batt: Float Charge
>PWR SUPPLY: Normal
Batt V Check Freq:
50 Cycles

BATTERY STATUS: Indicates the charging status:

FLOAT: When battery is FULL voltage and not being charged

BULK: Battery is in charging mode

ABSORPTION: Batteries are low, switches to charging

POWER SUPPLY VOLTAGE:

NORMAL (Default): Standard power supply

CHARGE: For retrofitting older systems only and replaces the original factory transformer

SOLAR: Used when you have Solar Panels

WARNING! If Solar is set to ON, and AC voltage is present, the AC voltage will not be connected and you will still be operating off batteries only!

Loss of **SOLAR** or **Power Supply** connection for 24 hours **(will cause a FLASHING ALERT warning screen)**

BATTERY V CHECK: How often the board will test the batteries under load. The factory pre-set is every 50 cycles. (Pass code required to change cycle frequency)

Additional VOLTAGE WARNINGS FAULTS & Screens: **AC is missing:** There is no AC voltage detected on the **GENESIS** board at the **AC INPUT**. **OVER VOLTAGE:** The voltage at the **AC INPUT** measured over the 30V in normal mode. **MOTOR OVER-CURRENT:** The motor current exceeded the high set point.

Voltage not
detected at the AC
Input

Voltage at the AC
Input measured over
30V in normal mode

Motor current went
above set point

>Low Battery Action
No Action
No Main Power Act.:
Run on Batteries

LOW BATTERY ACTION: Default is No Action

Options are:

FAIL SAFE: Gate will fail OPEN **(will cause a FLASHING ALERT warning screen)**

FAIL SECURE: Gate will fail CLOSED. **(will cause a FLASHING ALERT warning screen)**

NO MAIN AC POWER ACTION:

Options are:

RUN ON BATTERIES: If you lose AC power, your gate will continue to run on battery power

HOLD OPEN: If you lose AC power, your gate will lock up in the OPEN mode

WARNING! FAIL SAFE!
Gate held OPEN due
to critical low
battery voltage

WARNING! FAIL SECURE
Gate held CLOSED due
to critical low
battery voltage

>Low Battery Level
**Note: this screen
not viewable.
Requires passcode**

BATTERY LEVEL: During battery test, if the battery level falls below the level set, it will turn on the **FAULT LIGHT** and issue a **FAULT CODE**. (Passcode required to change). **(will cause a FLASHING ALERT warning screen)**

GENESIS CONTROL BOARD

MAINTENANCE (cont.)

WARNING! LOW BATTERY
Check charge
circuit, charge or
replace Batteries

OTHER FAULT CODES:

Battery issue: Check the charge voltage, check the Batteries or replaced if necessary.

FORCED OPEN DETECT: The gate was attempted to be opened and moved off the CLOSED limit without a command from the GENESIS board.

INTERNAL EEPROM & MISSING EEPROM: Internal EEPROM missing or defective

Gate has been moved
off the CLOSE limit
w/o a command from
the GENESIS board

Internal EEPROM
fault detected

EEPROM chip not
detected

>Over-Current Level:
20 Amps

OVER-CURRENT LEVEL: Adjusts the Internal Inherent Amp current level for the motor. On model 2490 systems with the **GENESIS** board and the **LPS SENSOR**, this will not be in effect. When using **LIMIT SWITCHES**, the **OVER-CURRENT LEVEL** must be set for obstruction/entrapment sensing. If the board senses an **OVER-CURRENT** it will reverse the gate on the first activation. On a sequential activation, this will stop the gate and turn on the UL Alarm. To reset.... Check for any obstructions, if none, Press the **STOP** button on the board or if you have an accessory **STOP** button wired to the **STOP** input. Other options are hit the **RESET** button or cycle all power off and on.

LOCKED
Key: EB60F3CA
- - - - -

CUSTOM SETTINGS: For advanced features. Requires a "PASSCODE" available from AutoGate only. Code is active for 24 hours only. After 24 hours a new code is required.

FAULT/LOGS/ALERTS

Fault/Logs/Alerts

OPTIONS: Fault log, Operation Log, Maintenance Alerts

Fault Log
>25 10:34p 04/20/18
Gate Angle Sensor

FAULT LOG: Running list of faults, stored for reference for diagnostic troubleshooting. The last 99 Faults are stored. The newest Fault will always be the first one shown. Any fault in the system will also turn on the **FAULT LIGHT** on the outside of the cabinet.

Operation Log
#06< 02:55p
06/29/18
Local Open

OPERATION LOG: All normal "operations" are recorded up to 99 events. (i.e. Close Limit, Open Limit, Green Open button, Red Stop button, entry Inputs, loop detections, & photoelectric sensors/beam detections, traffic lights, etc. are examples of normal "operation" events logged.)

>Maintenance Alerts
50K Cycles
Next due at 80,000

MAINTENANCE ALERT: Alerts the owner that maintenance is due after a selected number of cycles. This can be set by the installer for 10K, 20K or 50,000 cycles. The screen will show how long until the next alert will show.

>Maintenance
Required, Hold Stop
button & Press Jog
to clear.

MAINTENANCE ALERT: You have reached your predetermined number of cycles to perform general maintenance. Hold the **STOP** button and press the **JOG/Select** button to clear.

GENESIS CONTROL BOARD

FAULT LOG ENTRY	FAULT MENU DISPLAY
AC MISSING	Voltage not detected at the AC input
BATTERY LOW CHARGE	WARNING! Battery low, check battery charge voltage
CLOSE BEAM MISSING	If your “monitored” device is enabled and the required feedback (10K or Pulse) is missing
CLOSE EDGE MISSING	If your “monitored” device is enabled and the required feedback (10K or Pulse) is missing
DUAL GATE COMM. LOST	Gate set in DUAL mode: Primary or Secondary not detected
EMERGENCY SECURE	WARNING! EMERGENCY SECURE is enabled, gate will not OPEN until released
FAIL SAFE OPEN	WARNING! Fail Safe gate held open due to critical battery voltage
FAIL SECURE CLOSE	WARNING! Fail Secure gate held close due to critical battery voltage
FIRE HOLD ENABLED	WARNING! FIRE SWITCH IS ENABLED. Hold Stop and press Jog/select to clear
FORCED OPEN DETECT	Gate has been moved off the CLOSE limit position without a command from the GENESIS board
HOLD OPEN	WARNING! HOLD OPEN is enabled, gate will not close until released
INTERNAL EEPROM	Internal EEPROM fault detected
LPS SENSOR NOT DETECTED	LPS Sensor is not detected by the GENESIS board (not applicable in LIMIT SWITCH mode)
MAINTENANCE REQ'D.	Maintenance required, hold stop button and press Jog/Select to clear
MISSING EEPROM CHIP	EEPROM chip not detected
MONIT. INPUT MISSING	WARNING! Monitored input missing, see LED indicators for monitored inputs
MOTOR OVER-CURRENT	Motor current went above set point
NO CHARGE IN 24 HRS	WARNING! Charging source not detected in the last 24 hours
OPEN BEAM MISSING	If your “monitored” device is enabled and the required feedback (10K or Pulse) is missing
OPEN EDGE MISSING	If your “monitored” device is enabled and the required feedback (10K or Pulse) is missing
OVER VOLTAGE	Voltage at AC input measured over 30V in normal power mode
PGM. INPUT 1 MISSING	If your “monitored” device is enabled and the required feedback (10K or Pulse) is missing
PGM. INPUT 2 MISSING	If your “monitored” device is enabled and the required feedback (10K or Pulse) is missing
SPEED OVER-RUN	Downward speed was too fast
UL FAULT CONDITION	WARNING! DOUBLE DEFAULT. Push RED stop button or RESET button to restore to use
UL FAULT CONDITION	WARNING! OBSTRUCTION DETECTED! An intended input or RESET required to restore use